

# Installation, Operation, Maintenance Manual



## **NBC™ Belt** **Narrow Belt Conveyor** Accumulation with CRUZcontrol® & Transportation

IOM Part Number: 1118140  
Revision Date: August 01, 2022



[Para la OIM española  
seleccione aquí](#)

## TABLE OF CONTENTS

|                                                                    |           |
|--------------------------------------------------------------------|-----------|
| <b>1 IOM INTRODUCTION.....</b>                                     | <b>4</b>  |
| <b>2 MHS CONVEYOR POLICIES.....</b>                                | <b>5</b>  |
| 2.1 MHS RECOMMENDS PROPER LABELS FOR CONVEYOR TYPES.....           | 7         |
| 2.2 WARNINGS AND SAFETY INSTRUCTIONS .....                         | 8         |
| 2.3 MHS CONVEYOR CONTROLS SAFETY GUIDELINES.....                   | 11        |
| <b>4 NBC INTRODUCTION .....</b>                                    | <b>13</b> |
| 4.1 NBC FLAT BELT ACCUMULATION AND TRANSPORTATION CONVEYOR .....   | 13        |
| 4.2 NBC GUIDELINES .....                                           | 15        |
| 4.3 NBC TECHNICAL APPLICATIONS .....                               | 17        |
| 4.4 NBC GENERAL CAUTIONS.....                                      | 18        |
| 4.5 VALVE APPLICATIONS.....                                        | 19        |
| 4.6 DEFINITION OF TERMS .....                                      | 21        |
| <b>5 NBC RECEIVING AND SITE PREPARATION.....</b>                   | <b>22</b> |
| 5.1 PARTS INVENTORY AND IDENTIFICATION.....                        | 23        |
| <b>6 NBC INSTALLATION DETAILS.....</b>                             | <b>24</b> |
| 6.1 DIMENSIONAL REFERENCE POINTS.....                              | 24        |
| 6.2 SQUARING CONVEYOR .....                                        | 25        |
| 6.3 SUPPORTS & CONNECTIONS.....                                    | 26        |
| 6.4 ENVIRONMENT.....                                               | 26        |
| 6.5 COMPONENT ORIENTATION.....                                     | 26        |
| 6.6 ELEVATIONS .....                                               | 27        |
| 6.7 LINE STRAIGHTNESS.....                                         | 28        |
| <b>7 GEAR MOTOR ACTIVATION .....</b>                               | <b>29</b> |
| <b>8 NBC, NITTA BELT WELDING INSTRUCTIONS .....</b>                | <b>31</b> |
| <b>9 THREADING THE BELT.....</b>                                   | <b>33</b> |
| 9.1 THREADING BELT IN NBC TRANSPORTATION CONVEYOR .....            | 38        |
| <b>10 NBC AIR TAKE-UP.....</b>                                     | <b>39</b> |
| 10.1 500 LB.-AT. AND 250-AT30 DRIVE TENSIONING (AIR TAKE-UP) ..... | 39        |
| 10.2 NBC CROSS SECTIONS .....                                      | 42        |
| <b>11 NBC SKEWING NBC ROLLERS .....</b>                            | <b>43</b> |
| 11.1 FACTORY SKEW CHARGE SECTION .....                             | 43        |
| 11.2 MAINTENANCE SKEW SECTION.....                                 | 45        |
| 11.3 FINGER GUARDS FOR SKEWED MAINTENANCE PRESSURE ASSEMBLIES..... | 46        |
| 11.4 ROLLER CENTERS 2" .....                                       | 47        |
| 11.5 ROLLER CENTERS 3" .....                                       | 48        |
| 11.6 CRUZ®CHANNEL TO XENOROL® CHANNEL CONNECTIONS .....            | 49        |
| 11.7 GUARDRAIL MOUNTING ON NBC .....                               | 50        |
| 11.8 CRUZCHANNEL TO C6 NOSE PIECE.....                             | 52        |
| <b>12 NBC AIR SUPPLY REQUIREMENTS.....</b>                         | <b>53</b> |
| 12.1 AIR PRESSURE APPLICATION .....                                | 55        |

|                                                             |            |
|-------------------------------------------------------------|------------|
| 12.2 AIR REGULATOR LOCK OUT VALVE ON AND OFF POSITION ..... | 56         |
| <b>13 NBC LOGIC MODULE CONCEPTS .....</b>                   | <b>57</b>  |
| 13.1 CRUZCONTROL® LOGIC .....                               | 57         |
| 13.2 SETTING LOGIC MODULES .....                            | 59         |
| 13.3 BASIC AND PROGRESSIVE LOGIC.....                       | 60         |
| 13.4 APPLICATION – CRUZ®LOGIC.....                          | 64         |
| 13.5 A METHOD OF STOPPING THE COASTING PRODUCT .....        | 67         |
| 13.6 NBC COMPONENTS .....                                   | 69         |
| 13.7 FUNCTION MODULES.....                                  | 71         |
| 13.8 TERMINAL BLOCK DESCRIPTIONS.....                       | 74         |
| 13.9 JUMPER DESCRIPTIONS .....                              | 75         |
| 13.10 USE OF 115 VAC CONTROLS .....                         | 76         |
| 13.11 FUNCTION MODULE PART NUMBERS.....                     | 77         |
| <b>14 NBC POWER SUPPLY REQUIREMENTS .....</b>               | <b>80</b>  |
| 14.1 POWER SUPPLY REQUIREMENTS.....                         | 80         |
| 14.2 POWER SUPPLY WIRING .....                              | 81         |
| 14.3 ACCESSORIES.....                                       | 84         |
| <b>15 CRUZCONTROL ON SITE INSTALLATION.....</b>             | <b>87</b>  |
| <b>16 CONVEYOR FLOW.....</b>                                | <b>89</b>  |
| 16.1 OVERVIEW – MHS CONVEYOR CRUZCONTROL LOGIC MODULE ..... | 96         |
| 16.2 POWER SUPPLY.....                                      | 101        |
| <b>17 NBC MAINTENANCE &amp; TROUBLESHOOTING .....</b>       | <b>108</b> |
| 17.1 GENERAL PREVENTIVE MAINTENANCE .....                   | 108        |
| 17.2 TROUBLESHOOTING GUIDE – MECHANICAL/ELECTRICAL.....     | 112        |
| <b>18 NBC REPLACEMENT PARTS IDENTIFICATION.....</b>         | <b>114</b> |
| 18.1 SPARE PARTS PRIORITY LEVEL EXPLANATIONS.....           | 114        |
| 18.2 NBC DRIVE ASSEMBLY .....                               | 115        |
| 18.3 NBC AIR TAKE-UP.....                                   | 117        |
| 18.4 NBC DRIVE TRAIN.....                                   | 119        |
| 18.5 REPLACEMENT PARTS - NBC 500 DRIVE TRAINS.....          | 119        |
| 18.6 NBC PRESSURE ASSEMBLY.....                             | 121        |
| 18.7 NBC SKEWED PRESSURE PAN ASSEMBLY.....                  | 122        |
| 18.8 NBC DISCHARGE BRAKE ASSEMBLY.....                      | 123        |
| 18.9 NBC END PULLEY ASSEMBLY .....                          | 124        |
| 18.10 NBC 12 FT. CONTACT ACCUMULATION .....                 | 125        |
| 18.11 NBC LOGIC MODULE COMPONENT.....                       | 126        |
| 18.12 NBC 12 FT. CONTACT ACCUMULATION SKEWED ROLLERS .....  | 127        |
| 18.13 NBC 12 FT. CONTACT ACCUMULATION SKEWED ROLLERS .....  | 128        |
| <b>NBC REVISION HISTORY.....</b>                            | <b>129</b> |
| <b>WORKS CITED .....</b>                                    | <b>129</b> |
| <b>GENERAL MHS CONVEYOR .....</b>                           | <b>129</b> |
| <b>ABOUT MHS CONVEYOR.....</b>                              | <b>130</b> |

# 1 IOM INTRODUCTION

## IOM Purpose

It is the intent of MHS Conveyor, through this manual, to provide information that acts as a guide in the installation, operation, and maintenance of MHS Conveyor conveyors.

This manual describes basic installation practices, assembly arrangements, preventive maintenance, and assists in replacement parts identification.


This service manual is intended for use by personnel who are knowledgeable of installation and safe working practices on conveyor systems.

Not all applications and conditions can be covered; therefore, this manual is to be used ONLY as a guide.

If additional copies of this manual are needed or if you have any question concerning the conveyor, please contact your MHS Distributor or MHS Lifetime Services at 231-798-4547 or visit MHS at [www.mhs-conveyor.com](http://www.mhs-conveyor.com) for maintenance videos and other application information.

## Manual Structure

You should receive a separate documentation for each product line of MHS Conveyor implemented in your installation. You can identify the respective product line on the back of the folder or on the cover sheet of the IOM (Installation Operation Maintenance Manual)



## WARNING



- Pay attention to the safety instructions!
- Prior to working at or in the immediate vicinity of the system it is recommended that you make yourself familiar with the safety instructions included in the present document!

## 2 MHS CONVEYOR POLICIES

### MHS Conveyor Equipment Warranty

MHS Conveyor warrants that the material and workmanship entering into its equipment is merchantable and will be furnished in accordance with the specifications stated.

MHS Conveyor agrees to furnish the purchaser without charge any part proved defective within 2 years from date of shipment provided the purchaser gives MHS Conveyor immediate notice in writing and examination proves the claim that such materials or parts were defective when furnished. For drive components specific to XenoROL® (i.e., Xeno belts, slave Xeno belts, drive spools, standard and speed-up, and spacers), this warranty shall be extended to five years of running use, provided the conveyors are applied, installed and maintained in accordance with MHS Conveyor published standards. Other than the above, there are no warranties which extend beyond the description on the face hereof. Consequential damages of any sort are wholly excluded.

The liability of MHS Conveyor will be limited to the replacement cost of any defective part. All freight and installation costs relative to any warranted part will be at the expense of the purchaser. Any liability of MHS Conveyor under the warranties specified above is conditioned upon the equipment being installed, handled, operated, and maintained in accordance with the written instructions provided or approved in writing by MHS Conveyor.

The warranties specified above do not cover, and MHS Conveyor makes no warranties which extend to, damage to the equipment due to deterioration or wear occasioned by chemicals, abrasion, corrosion or erosion; Purchaser's misapplication, abuse, alteration, operation or maintenance; abnormal conditions of temperature or dirt; or operation of the equipment above rated capacities or in an otherwise improper manner.

THERE ARE NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, EXTENDING BEYOND THOSE SET FORTH IN THIS STATEMENT OF WARRANTY.

Rev 08/12/2021



### MHS Environment Standards

MHS Conveyor equipment is designed to be installed in a clean, dry warehouse environment. Exposure to extreme humidity, direct sunlight, blowing dirt or rain can permanently damage some components of MHS Conveyor. In particular, the curing agents in concrete are known to attack and degrade the urethane conveyor components.

When installing conveyor on a new construction site, be sure that the concrete is properly cured before setting conveyor on it. In addition, if conveyors are stored in the proximity of curing concrete, proper ventilation must be used to direct the curing agent fumes away from the conveyor.




Failure to comply with these guidelines will void the MHS warranty on any failed components that result from these environment issues.

08/12/2021

|                                                                                                  |                                                                                                                                  |
|--------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
|  <b>WARNING</b> |                                                                                                                                  |
|                 | <ul style="list-style-type: none"><li>• Safety: Always lock out power source and follow recommended safety procedures.</li></ul> |

## 2.1 MHS RECOMMENDS PROPER LABELS FOR CONVEYOR TYPES

Shown below are some samples of labels applicable to conveyor standards.



## 2.2 WARNINGS AND SAFETY INSTRUCTIONS

Failure to follow the instructions and cautions throughout this manual and warning label on the conveyor may result in injury to personnel or damage to the equipment.

Your MHS Conveyor is powered by a motor and can be stopped only by turning off electrical power to the motor. As with all powered machinery, the drive-related components – including sprockets, chains, shafts, universal joints, and pneumatic devices – can be dangerous. We have installed or provided guards to prevent accidental contact with these parts, along with warning labels to identify the hazards.

Special attention must be paid to the following areas of this manual:

### **DANGER**



- Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations.

### **WARNING**





- Indicates potentially hazardous situation which, if not avoided, could result in minor or moderate injury. It may also be used to alert against unsafe practices.

### **CAUTION**

- Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



### 2.2.1 Warnings and Safety Instructions

|  <b>WARNING</b> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                 | <ul style="list-style-type: none"> <li>• After maintenance, REPLACE guards immediately.</li> <li>• Keep ALL warning labels clean and clear of any obstructions.</li> <li>• Never remove, deface, or paint over WARNING or CAUTION labels. Any damaged label will be replaced by MHS Conveyor at no cost by contacting Lifetime Services.</li> <li>• It is very important to instruct personnel in proper conveyor use including the location and function of all controls.</li> <li>• Special emphasis must be given to emergency stop procedures.</li> <li>• It is important to establish work procedures and access areas, which do not require any part of a person to be under the conveyor.</li> <li>• It should be required that long hair is covered by caps or hairnets.</li> <li>• Loose clothing, long hair, and jewelry must be kept away from moving equipment.</li> <li>• Maintain enough clearance on each side of all conveyor units for safe adjustment and maintenance of all components.</li> <li>• Provide crossovers or gates at sufficient intervals where needed to eliminate the temptation for personnel to climb over or under any conveyor.</li> <li>• Walking or riding on a moving conveyor must be prohibited.</li> <li>• Before performing maintenance on the conveyor, make sure the start-up controls are locked out and cannot be turned on by any person other than the one performing the maintenance.</li> <li>• If more than, one crewmember is working on the conveyor, EACH CREW MEMBER MUST HAVE A LOCK ON THE POWER LOCKOUT.</li> <li>• All pneumatic devices must be de-energized, and air removed to prevent accidental cycling of the device while performing general maintenance.</li> <li>• Make sure all personnel are clear of all conveyor equipment before restarting the system.</li> <li>• Before restarting a conveyor, which has been stopped because of an emergency, an inspection of the conveyor must be made, and the cause of the stoppage determined. The starting device must be locked out before any attempt is made to correct the cause of stoppage.</li> </ul> |



## WARNING



- Before servicing or performing any work in the motor control panel, disconnect and lock out air and the main incoming service. If only the panel disconnect is off, the incoming side will still be hot.



## 2.3 MHS CONVEYOR CONTROLS SAFETY GUIDELINES

The following basic conveyor control safety guidelines are recommended by MHS Conveyor even though Business Partner may or may not purchase conveyor controls from MHS Conveyor. The items listed deal with applications of controls equipment. The actual installation of the equipment must always follow the National Electric Code and all other local codes.

### Start-up Warning Horn

Ideally, all conveyors should be within sight of the conveyor start pushbutton. This allows the operator to verify that no one is touching the conveyor or would be in danger if the conveyor were to start up. If it is not possible to see the entire conveyor being started from the start pushbutton location, then some form of audible warning device is required. It could be a horn, buzzer, bell, or anything unique to that conveyor for that location. It should be loud enough to be heard at any point on the conveyor system. It should sound for approximately five seconds after the start pushbutton is pushed, prior to the actual running of conveyor. Any auxiliary equipment such as vertical lifts, turntables, etc., should also be included in the warning circuitry.

Conveyors that stop and restart under automatic control could also require a horn warning prior to restarting. If it is not easy to distinguish the difference between a fully stopped conveyor system and a momentarily stopped conveyor section, then it is advisable to add a warning horn. All conveyor sections that stop and restart automatically should be marked with appropriate signs or labels.

### Start Pushbuttons

Start pushbuttons should be the flush type or guarded such that inadvertently leaning against them will not actuate the conveyor. They should be provided with a legend plate clearly defining which conveyors will be started.

### Stop Pushbuttons

Stop pushbuttons should be the extended type such that any contact with it is sufficient to stop the conveyor. They would also be provided with a legend plate clearly defining which conveyors will be stopped.

### Operator Controls

Additional operator controls should be designed into the system with the same guidelines that go into start and stop pushbuttons, depending upon their function. Devices which are repeated on multiple control stations, such as emergency stops, should be located at the same relative location on each station (such as lower right corner).

### Emergency Stops

All locations where an operator must work directly at the conveyor should be protected by an emergency stop. An operator should not have to move from where he is to actuate the emergency stop.

Conveyors in areas of high pedestrian traffic should also be protected by emergency stop devices.

For all other instances, emergency stops should be located throughout a system such that it is possible to shut down the system without having to walk too far. In these instances, the emergency stop is used more to protect the equipment from damage than to protect personnel.

Emergency stops can be of the pushbutton or cable operated switch type. The pushbutton type should be a red, mushroom head maintained pushbutton which requires resetting after it is actuated. Cable operated switches should trip by pulling the cable and require resetting at the switch.

Actuating an emergency stop must drop-out the start circuit, requiring restarting the system using the start pushbuttons provided.

An emergency stop should normally stop all conveyors in the system. Very large systems may involve dividing a system into zones of control based on proximity of personnel, safety hazards, walls obstacles, etc.

### **Controls Logic**

Solid state controls logic devices, such as programmable controllers are used extensively for conveyor control. They are very reliable, but a hardware failure or software bug would cause an output to function erratically. For this reason, start circuits, warning horn circuits, and emergency stops should usually be configured using conventional relay logic.

### **Safety Switches**

All conveyor control cabinets and motors should be provided with safety (or disconnect) switches. These switches must have provisions for padlocking. As required for maintenance, equipment should be locked in the off position.

### **Special Devices**

Special devices and equipment such as vertical lifts, turntables, high speed conveyors, etc., all have unique design and safety requirements. These should be looked at in each case to determine what the requirements might be.

Rev 08/12/2021

## 4 NBC INTRODUCTION

---



*NBC flat belt contact accumulation*

### 4.1 NBC FLAT BELT ACCUMULATION AND TRANSPORTATION CONVEYOR

#### Concept and Operation

NBC flat belt conveyor is offered in contact accumulation and transportation versions.

The conveyor differences are as follows:


#### Contact Accumulation

The NBC contact accumulation zones are 4' long but operate in such a manner as to allow mixed length product to dense pack accumulate. The products are allowed to touch and bump but are at zero-pressure accumulation after they stop. The minimum speed for dense packing of product is 90 FPM for totes and 125 FPM for corrugated product.


The product-carrying rollers are driven by a nominal 1.75" wide belt. This belt is held in contact with the underside of the carrying rollers by spring pressure roller channel assemblies, mounted on the conveyor side channels.

Accumulation begins when a product blocks the first sensor from the discharge end. The first product stops over the discharge sensor which "arms" the next sensor upstream while lowering the belt pressure roller channel in that zone.

When a zone accumulates, each spring pressure roller channel assembly in that zone lowers by the use of an air diaphragm. The belt is lowered away from the carrying rollers causing them to become non-powered. Products are conveyed to the zone; then coast as they enter the non-powered area and bump into the stopped downstream product. As accumulation takes place from zone-to-zone, the accumulated products are at zero-line-pressure.



*NBC Pressure Pan – spring-to-drive rollers, air-to-accumulate*



*NBC Logic Module Assembly*

## Transportation

The NBC transportation has the same spring loaded pressure pans as the accumulation versions, but no air diaphragm to disengage the pressure pan. A plastic Cam can be manually activated to lock the pressure pan in the down position for ease of belt installation. However, once the plastic Cam is manually deactivated, the pressure pan always holds the drive belt in contact with the carrier roller.

## Air Transportation

Air transportation uses air diaphragms to retract the pressure assemblies rather than the plastic lockout Cam. All the diaphragms are linked together to a central valve which is designed to disengage the entire line at once. There are no logic modules for individual zone accumulation.

## 4.2 NBC GUIDELINES

1. Accumulation or transportation as required
2. Product-to-product contact is allowed
3. Singulation of product release is not required
4. Product weight: 1-75 lbs. (50 lbs. /ft.)
5. Product height: 1" minimum
6. Product may be same size and weight, or mixed
7. Air supply is dry

### Application Notes

1. NBC does not singulate products.
2. Conveyor operations before and after NBC are vital to proper application decisions.
3. The conveyor downstream from progressive release NBC must run at a speed which allows it to receive products as fast as they are released from the NBC conveyor.
4. There will not be a gap or means of detecting a specific product, directly on the end of NBC without a downstream speed-up bed.
5. When feeding sortation from NBC, use a split metering belt to singulate individual products when specific minimum gap is required.
6. NBC cannot be fed from an upstream conveyor at a rate exceeding the NBC rate, especially from a curve.
7. Convey all products along one side of NBC unless products are nearly the same width and closely match the conveyor width. Skewing beds are available to accomplish this.
8. During accumulation, product density (packing) increases with product weight and speed.
9. For all applications, Nitta belt shall be used.
10. Under no circumstances shall a mechanical lace be used with the Nitta blue urethane welded belt MHS Conveyor P/N 1205548.
11. NBC conveyor requires a MHS Conveyor Nitta Belt Welding Tool Kit for splicing the belt. This tool kit was developed by Nitta Corporation for MHS Conveyor NBC belt requirements and are available only from MHS Conveyor.
12. Limit the length of NBC conveyors to 300'. If you have a requirement beyond 300' contact Applications Engineering.
13. Always locate the drive bed at the charge end of the primary conveyor.
14. Totes may have up to a 2" taper on each end without affecting the function of the electronic sensors. Customers who have tapered totes may request MHS Conveyor to perform a product test with test product supplied by the customer.
15. All accumulation conveyors require a discharge brake zone up to 129 FPM unless discharging to belt unit. For speeds at 130 FPM and above, a pivoting blade stop, blade stop, or brake belt unit is required.
16. Due to the direct drive train, speeds may vary +/- 10% from stated speeds.
17. The minimum bed length for all NBC Flat Belt drives is 8'.
18. The 250-AT30 has an air take-up with a maximum belt take-up of 30", a maximum belt pull of 250 lbs. and is used for lengths from 12' to 100'.
19. The 500-AT has an air take-up with a maximum belt take-up of 55", a maximum belt pull of 500 lbs. and is used for lengths from 12' up to 220'.

20. Use the NBC Application Program to determine the drive style (250-AT30 or 500-AT) and horsepower size based on rate and speed requirements.
21. Take away speed to be equal or greater than NBC Flat Belt.
22. Pricing includes bed, end assemblies, and belting.
23. Floor supports are not included. See Support and Connections for details.
24. Maximum amount of continuous skew is 12' not including maintenance skews.

#### Temperature

25. Ambient temperature is +35° to +120°F for Nitta belts.
26. For applications outside this temperature range, contact Applications Engineering.



### 4.3 NBC TECHNICAL APPLICATIONS

Product delivery (release) following accumulation is always an important application consideration. The product release rate depends on the release logic, conveyor speed, gaps between products, and the product length. In all situations that require dense product packing, the conveyor should NOT run below 125 FPM for cartons and 90 FPM for totes.

Release efficiency is the ratio between conveyor speed (feet per minute) and the product footage delivered (case feet per minute). One variable is the amount of gaps between products before release. These gaps are due to product coast when accumulating. (See Coast-ability) Additional gaps can occur at release dependent on the logic used.

When dense packing in a cool environment (35° to 50°) a minimum speed of 150 FPM is required.

#### Release Efficiencies

Overall release efficiency with a single continuous release may vary.

- Contact Accumulation
- 40% with Basic Logic (40% product / 60% air)
- 80% with Progressive Logic (80% product / 20% air)

Release efficiencies are dependent on the case size, mix, weight, conveyor speed, whether Basic or Progressive logic is used with the release operation. When the speed to meet rate using Basic Logic is over 150 FPM, consider using Progressive Logic

**In the progressive release mode for contact accumulation, it is extremely important to set every 5th logic module to basic.**

#### Discharge Zone

A function module is provided for the discharge bed prior to shipping. If the NBC line is feeding another NBC line, a release type function module is not required.


#### Horsepower Principles

The horsepower required for NBC conveyor is based on the effort (in pounds) to pull the belt through the conveyor (belt pull), turning all the rollers and moving the product at a given speed. Actual horsepower is based on “effective belt pull”, which includes a factor for belt flexing, bending, and snubbing.

#### Coastability

Product coast is affected by many factors involving the product and conveyor. When one product does not coast up to the previous product, a gap occurs. Some gaps are likely within a zone. This is not a problem if considered when determining the conveyor

speed. Factors determining coast are; product bottom - smoothness, firmness, straightness; product weight; product length relative to zone length; conveyor speed; roller bearing friction, rollers still turning from previous product movement or rollers which have stopped.



#### 4.4 NBC GENERAL CAUTIONS

- Singulating individual product out of NBC requires a MHS Conveyor application review. Consult Applications Engineering for available options.
- Do not pitch NBC either up or down. When product accumulates, the conveyor turns to gravity and product control is lost.
- Do not overfeed downstream conveyor with either Basic or Progressive release. This will create line pressure.
- The minimum package length is 9". The minimum package height is 1". The maximum product weight is 50 lbs. /ft.
- Small light products that fit between a zone sensor and the end of the zone may rotate and/or accumulate side by side. Consult Applications Engineering for available options.
- Rollers in the center 4' zone in all 12' intermediate beds are designed to skew if required. No other rollers in the bed can be skewed. Any NBC conveyor that has skewed rollers without proper installation will immediately and permanently **VOID ALL MHS Conveyor WARRANTIES.**
- Make sure air is preset, and take-up engages before operating the NBC conveyor.


4.5 VALVE APPLICATIONS

NBC Air Transportation Conveyor

NBC Flat Belt Air Transportation is typically used in conjunction with a downstream NBC Flat Belt Contact Accumulation conveyor.


Air Pilot Valve

NBC Air Transportation should be used when downstream accumulation is full. The air pilot valve receives a signal from the last downstream accumulation zone and disengages the pressure pan assemblies for the entire unit. Once the downstream zone clears, the pilot valve engages the pressure pan assemblies and the transportation conveyor will continue to transport the products. The pilot valve can be replaced with a solenoid valve and controlled through a PLC.



| Pilot Valve |                      |
|-------------|----------------------|
| Item#       | Description          |
| 1120400     | VALVE,PNEU-PILOT-A48 |

Solenoid valve



The Solenoid Valve Kit is controlled by an external signal from the primary control system supplied by the purchaser. The Solenoid Valve Kit is typically mounted near the last NBC contact accumulation zone prior to the upstream NBC Air Transportation conveyor.

| Solenoid Valve |                                                   |
|----------------|---------------------------------------------------|
| Item#          | Description                                       |
| 1206186        | KIT,CPART-SOL VALVE-24V-NBC AIR TRANS-VALVE OPEN  |
| 1206187        | KIT,CPART-SOL VALVE-110V-NBC AIR TRANS-VALVE OPEN |

The valve is normally open when no signal is present, which causes the NBC Air Transportation conveyor to stop or accumulate. When the last NBC Contact Accumulation zone clears, a control signal triggers the Solenoid Valve to activate (close or stop the air flow), and the NBC Air Transportation conveyor will activate and convey the product downstream. Review the detail above to determine correct Pilot or Solenoid Valve Kit on the NBC Contact Accumulation conveyor flow.

## 4.6 DEFINITION OF TERMS

### Logic Assembly

The logic assembly is used to setup the type of automatic accumulation of product on the conveyor.

### ATB

Air-to-brake (Type of Logic assembly used in NBC conveyors – Normally Open Valve)

### Function Module

The function module provides electrical isolation for external signals used to control a CRUZcontrol system.

### Downstream or Upstream

In this manual, it is always in reference to product conveyor flow.

### OFF

Off indicates a logical low signal and/or no power. For example, if a logic line is OFF, there is no power on the logic line.

### ON

On indicates a logical high signal and/or powered. For example, if a slug line is ON, then there is power on the slug line.

### Zone status

The zone is considered full if the local zone's sensor detects a package. The zone is empty if it does not detect a package

### JP#, #-#

JP stands for "jumper terminal" and the number indicates which jumper terminal is being referenced. The "#-#" refers to the pins that are connected by the actual jumper. NC means the jumper is not connected to any terminal.

Ex. jumper terminal #1 pins 1 & 2 (JP1, 1-2)

### TB#, #-#

TB stands for "terminal block" and the number indicates which terminal block is being referenced. The "#-#" refers to the pins that are being used on that terminal block.

Ex. terminal block #1 pins 1 & 2 (TB1, 1-2)

## 5 NBC RECEIVING AND SITE PREPARATION

---

### Receiving

MHS Conveyor NBC flat belt conveyors are shipped in subassemblies. These subassemblies are packaged to guard against damage in shipment when handled properly.

Examination immediately following unloading will show if any damage was caused during shipment. If damage is evident, claims for recovery of expenses to repair damaged or replace components must be made against the carrier immediately. While unloading, a check must be made against the Bill of Lading, or other packing lists provided, to confirm full receipt of listed items.

### CAUTION

- TAKE CARE DURING THE REMOVAL OF EQUIPMENT FROM THE CARRIER. Remove small items and boxes first. Pull and lift only on the skid, not on the frame, crossmember or any part of the equipment.
- Be sure the skid is free of other materials which may be on top of or against the side of the skid to be removed.



*Conveyor ready for shipment*

### Preparation of Site

After the conveyor is received, move it to the installation site or designated dry storage area as soon as possible. Clean up all packing material immediately before parts are lost in it, or accidentally discarded. Loose parts should remain in the shipping boxes until needed. Prior to starting the assembly of the conveyor, carefully check the installation path to be sure there are no obstructions that will cause interference. Check for access along the path needed to bring in bed sections and components closest to the point where they are needed. It is often necessary to give the area along the system path a general cleanup to improve installation efficiency, access, and accuracy.

## 5.1 PARTS INVENTORY AND IDENTIFICATION

Each subassembly is shipped completely assembled except typical loose parts, which are in boxes with the subassemblies. Segregate the conveyor subassemblies by types for inventory and ease of locating during installation.

An identification label is attached to the outside of one side channel close to one end of each conveyor bed and on all drive packages. On supports, the tag is located on the crossmember. Labels **may** contain the following information:

New style labels have the following:

- Item number
- Description
- Job Number
- Mfg. Number
- Tag number (if specified)
- Assembler's clock number
- Date of manufacture
- QR (Quick Response) bar code
  - Scan bar code for IOM manual



If Applicable - Scan the QR code to retrieve the IOM Manual, if nothing happens; check your scanner settings to make sure the QR Label setting is enabled. On the supports, the tag is located on the bottom side of the foot.

On special devices, it is located on a convenient flat surface that is not offensive to the appearance of the equipment but is still accessible for viewing. These numbers can be cross-referenced against the packing list.

Loose parts are boxed and shipped separately. You should have all conveyor sections and supports for a particular conveyor prior to installation. It is cost-effective to identify and procure any missing parts before they are needed for assembly. Small items like nuts and bolts are weigh-counted and packaged by size and type.







Identification labels

## 6 NBC INSTALLATION DETAILS

### NBC General Procedures

The following procedures are to be used as guidelines only. Specific installation methods will vary somewhat depending on available equipment on site and each installer's preferences based on past experience.

|  <b>WARNING</b> |                                                                                                                                                                                                                                                                  |
|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                 | <ul style="list-style-type: none"> <li>The Installation Supervisor must be experienced with conveyor, qualified in the mechanics of the equipment, enforce safe working procedures for the protection of the crew, customer, and customer's property.</li> </ul> |

|  <b>WARNING</b> |                                                                                                                                                                                                                                                                                                                         |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               | <ul style="list-style-type: none"> <li>Before restarting a conveyor which has been stopped because of an emergency, an inspection of the conveyor must be made and the cause of the stoppage determined. The starting device must be locked out before any attempt is made to correct the cause of stoppage.</li> </ul> |

### 6.1 DIMENSIONAL REFERENCE POINTS

The path of each conveyor in the system is determined by establishing a reference point at each end. The center line of the conveyor is established and a chalk line is snapped between these points.

Conveyors should be installed with the center line of the bed matching the center line of the conveyor path within 1/8" of true center. Locate and mark the center of the crossmembers at each end of the conveyor. Use a plumb line or other acceptable means to ensure accuracy to the chalk line.

Always carry out a thorough check for any obstructions such as building columns, manholes, etc. It may be necessary to reroute the conveyor to avoid the obstruction. In this case it would be advisable to begin installation at this point, using the obstruction as a reference point (Datum), and install the section in either direction as required.



## 6.2 SQUARING CONVEYOR

All conveyor sections must be checked for squareness prior to installation as “racked” or being knocked out of square may have occurred during shipping and handling. An out of square conveyor section is a leading cause of belt mistracking. Measure diagonally across the four corners of the conveyor frame to determine if frame is out of square. If the measurement is not equal between the two diagonals, the frame is not square. A “racked” conveyor will skew the rollers, causing the belt to wander off center.


The conveyor sections are joined together with welded butt plate connectors. If a conveyor section is determined to be out of square, adjustment must be made before proceeding to the next section. Correct the squareness of the conveyor frame by installing a tie rod along the longest diagonal dimension and adjusting the turnbuckle until the diagonal measurements are equal in length. It is important to loosen the support and connection hardware before attempting any adjustment.

If gaps appear between bed joints as a result of squaring the conveyor, take care not to “re-rack” the conveyor by pulling the sections together at the bed joints. Insert optional shim plates or washers to the required thickness to fill the gap before tightening the connection hardware. Verify the squareness of the conveyor after installation.

### CAUTION

- An out of square conveyor section is a leading cause of belt mistracking.

**LOOSEN SUPPORT AND CONNECTION HARDWARE BEFORE ATTEMPTING ANY ADJUSTMENT.**



MEASURE DIAGONALLY ACROSS THE FOUR CORNERS.  
 IF Y-Y DIMENSION IS GREATER THAN X-X, ASSEMBLY TIE ROD AS SHOWN.  
 IF X-X DIMENSION IS GREATER THAN Y-Y, ASSEMBLY TIE ROD ACROSS THE OPPOSITE DIAGONALS.  
 ADJUST TURNBUCKLE UNTIL DIAGONAL MEASUREMENTS ARE EQUAL IN LENGTH ( $\pm 1/16"$ ).

ICM-NBC031

*Squaring conveyor*

## 6.3 SUPPORTS & CONNECTIONS

For details on Supports & Connections, see Support & Connections IOM (#1200485) at

[mhs-conveyor.com](https://mhs-conveyor.com)

## 6.4 ENVIRONMENT

### **Temperature range (ambient):**

+35° to +120°F. For applications that exceed this temperature range, please consult Applications Engineering.

### **Oily or Wet Conditions:**

Will impair frictional drive characteristics.

### **Corrosive or Abrasive Substances:**

Will adversely affect various components

## 6.5 COMPONENT ORIENTATION

Using your conveyor system layout drawing and the numbers on the I.D. tags of each component position and orient the conveyor section.

You must know:

- The direction of product flow
- The elevation height
- How the drive is positioned
- Charge and discharge end beds

**IMPORTANT!** Do not make alterations to the equipment without consulting with user's representative and MHS Conveyor. Unauthorized modifications to the equipment may impair its functions, create a hazardous condition, affect its useful life and /or void the warranty.

## 6.6 ELEVATIONS

All conveyor sections should be installed in accordance with the elevations shown on the drawings. In addition, they must be level across the frame width and length (if horizontal). Leveling of the frames is best done using a rotating laser level or builder's level.

After the first elevation is established at a critical point, the elevation of all other points shall be relative to this first point. Normal practice is to dimension the layout and measure elevations from the floor at each point of support.


As the conveyor system proceeds onto another floor or into another building or room, a new elevation will be measured from the floor at that point. The new elevation will then become the reference from subsequent elevations.

When installing an overhead system, the first elevation is measured from the floor and becomes the reference elevation point until a change in the elevation is shown on the layout. Any new elevation is also measured from the floor and becomes the new reference point. The process is repeated each time an elevation change occurs.

### CAUTION

- Consult the building architect or a structural engineer regarding ceiling loading or structural limitations of the building if any conveyor section is ceiling hung.
- MHS Conveyor is not responsible for permits regarding ceiling load data.

## 6.7 LINE STRAIGHTNESS





## CAUTION

- Line straightness must be maintained or belt will miss-track and result in damage to the conveyor.


## 7 GEAR MOTOR ACTIVATION

**PRIOR** to systems activation - Please inspect the gear unit for a vent and if applicable to the product remove the rubber sealing plug to activate. The vent is designed to allow excessive pressure to escape. Each gear unit should have a yellow instruction tag as shown below. The tag can be removed after the plug is removed.

**NOTE:** The rubber sealing plug is in place for shipping and storage purpose only.

|  <b>WARNING</b> |                                                                                                                                                                                                       |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                 | <ul style="list-style-type: none"><li>• In order for the gear motor to release pressure, the vent must be activated by removing the rubber sealing plug <b>PRIOR</b> to gear unit start up.</li></ul> |

Please check you gear unit for a vent and if applicable to your product, remove the sealing plug to activate. "<https://www5.nord.com>" Operation Manual for Gear Units (B1000).



**NOTE:** Yellow tags may be tucked out of sight. Please inspect all motors for a vent and remove sealing plug, if present, to activate.

The following pictures are examples showing where vent plugs may be located depending on the product line and motor position.



## 8 NBC, NITTA BELT WELDING INSTRUCTIONS

NBC, MHS Conveyor Nitta Belt Welding Instruction.

To rent or purchase parts contact MHS Conveyor Lifetime Services at 231-798-4547.

MHS Conveyor Nitta Belt Weld Instruction Manual #1120515 or

MHS Conveyor Nitta Belt Weld Instruction Maintenance Video at:

[mhs-conveyor.com](https://mhs-conveyor.com)

### MHS ConveyorNitta Belt Welder Press Rental Kit:

| MHS Conveyor NITTABELT FULL WELD & PUNCH KITS<br>(RENTAL KITS ONLY!)                                                                                                                                                      |                                                                                                         |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| Item #                                                                                                                                                                                                                    | Description                                                                                             |
| 1207112                                                                                                                                                                                                                   | TOOL,NBC-NITTA-RENTAL-WELDER KIT-FULL                                                                   |
| MHS Conveyor Rental Kit Include: Finger Punch Press, T-wrench, Heated Weld Press, Pre-setter Mold, Silicone Sheet, Instruction Manuals, and Flash Drive with Instruction Video. Each Press Kit Is Shipped in a Hard Case. |                                                                                                         |
| NITTABELT WELDER AND PUNCH HARD CASE<br>WITH SPECIAL MOBRIK FOAM                                                                                                                                                          |                                                                                                         |
| Item #                                                                                                                                                                                                                    | Description                                                                                             |
| 1211171                                                                                                                                                                                                                   | CASE, PELICAN 1560-000-110-BLACK CASE, W/ SPECIAL MOBRIK-FOAM #BW1560<br>(HOLDS THE WELDER & PRESETTER) |
| 1211172                                                                                                                                                                                                                   | CASE, PELICAN 1620-020-110-BLACK CASE, W/ SPECIAL MOBRIK-FOAM #BW1620<br>(HOLDS THE PUNCHER)            |




## CAUTION

### **WARNING:**

- Use Only MHS Conveyor Nitta belt welder and punch equipment for MHS Conveyor Nitta belt splice/welding. Non-MHS Conveyor Nitta belt welding or punch equipment is not compatible with the MHS Conveyor Nitta belt!



*Top side of blue urethane belt after weld*



*Bottom side of blue urethane belt after weld*



## CAUTION

- Never field splice NBC Nitta blue urethane belt (MHS Conveyor P/N 1205548) with mechanical lacing, as the belt fabric is not designed to hold lacing.

### 8.1.1 Replacement Parts - Nitta belt Welding

| MHS Conveyor NITTA BELT FULL WELD & PUNCH KITS<br>(RENTAL KITS ONLY!)                                                                                                                                                     |                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| Item#                                                                                                                                                                                                                     | Description                                                                                                 |
| 1207112                                                                                                                                                                                                                   | TOOL,NBC-NITTA-RENTAL-WELDER KIT-FULL                                                                       |
| MHS Conveyor Rental Kit Include: Finger Punch Press, T-wrench, Heated Weld Press, Pre-setter Mold, Silicone Sheet, Instruction Manuals, and Flash Drive with Instruction Video. Each Press Kit is Shipped in a Hard Case. |                                                                                                             |
| NITTA BELT WELDER AND PUNCH HARD CASE<br>WITH SPECIAL MOBRIK FOAM                                                                                                                                                         |                                                                                                             |
| Item#                                                                                                                                                                                                                     | Description                                                                                                 |
| 1211171                                                                                                                                                                                                                   | CASE, PELICAN 1560-000-110-BLACK CASE, W/ SPECIAL MOBRIK-FOAM #BW 1560<br>(HOLDS THE WELDER & PRE SETTER)   |
| 1211172                                                                                                                                                                                                                   | CASE, PELICAN 1620-020-110-BLACK CASE, W/ SPECIAL MOBRIK-FOAM #BW 1620<br>(HOLDS THE PUNCHER)               |
| NITTABELT                                                                                                                                                                                                                 |                                                                                                             |
| Item#                                                                                                                                                                                                                     | Description                                                                                                 |
| 1205548                                                                                                                                                                                                                   | BELT,NBC-1.75"W-CFTG-BLU-U-WLD<br>(WELD ONLY!)                                                              |
| NBC NITTA BELT COMPLETE WELDER KIT<br>(PURCHASE ONLY)                                                                                                                                                                     |                                                                                                             |
| Item#                                                                                                                                                                                                                     | Description                                                                                                 |
| 1207241                                                                                                                                                                                                                   | TOOL,NBC-NITTA-PURCHASE-WELDER KIT-FULL                                                                     |
| Include: Heated Weld Press and Nitta NPS-2005-1/2 Manual , Finger Punch Press, T-wrench & Nitta FP-200T Manual, & Pre-setter Mold with 1 Silicone Sheet                                                                   |                                                                                                             |
| WELDING PRESS                                                                                                                                                                                                             |                                                                                                             |
| Item#                                                                                                                                                                                                                     | Description                                                                                                 |
| 1204524                                                                                                                                                                                                                   | TOOL,NBC-NITTA BELT-PRESS-HEATING/COOLING 110V                                                              |
| 1204526                                                                                                                                                                                                                   | TOOL,NBC-NITTA-SILICONE SHEET-USE WITH PRE-SETTER<br>Include: Heated Weld Press & Nitta NPS-2005-1/2 Manual |
| REPLACEMENT PARTS - FOR WELDING PRESS                                                                                                                                                                                     |                                                                                                             |
| Item#                                                                                                                                                                                                                     | Description                                                                                                 |
| 1207117                                                                                                                                                                                                                   | TOOL,NBC-NITTA BELT-PRE-SETTER-W/SILICONE SHEET-1.75"W                                                      |
| FINGER PUNCH PRESS                                                                                                                                                                                                        |                                                                                                             |
| Item#                                                                                                                                                                                                                     | Description                                                                                                 |
| 1204525                                                                                                                                                                                                                   | TOOL,NBC-NITTA BELT-PUNCHER-FINGER PUNCHER<br>Include: Finger Punch Press, T-wrench & Nitta FP-200T Manual  |
| REPLACEMENT PARTS - FOR FINGER PUNCH PRESS                                                                                                                                                                                |                                                                                                             |
| Item#                                                                                                                                                                                                                     | Description                                                                                                 |
| 1207004                                                                                                                                                                                                                   | TOOL,CPART-NITTA-BLADE(2)-CUTTERS FOR USE WITH FP-200T                                                      |
| 1207118                                                                                                                                                                                                                   | TOOL,NBC-NITTA-T-WRENCH-USE WITH PUNCH PRESS                                                                |
| 1207119                                                                                                                                                                                                                   | TOOL,NBC-NITTA-CUTTING BOARD-USE WITH PUNCH PRESS                                                           |
| 1215576                                                                                                                                                                                                                   | SCREW, HEX HEAD NITTA-NO2-FP200-A003-19                                                                     |
| 1215577                                                                                                                                                                                                                   | TABLE,ALGND NITTA-NO2-FP200-P011-E-RA                                                                       |




MHS Conveyor P/N 1204526: Pre-setter Mold & Silicone Sheet



MHS Conveyor P/N 1207117: Silicone Sheet



MHS Conveyor P/N 1207119: Cutting Board



MHS Conveyor P/N 1207004: Cutting Blade




## 9 THREADING THE BELT

### Step 1

The most important item in threading NBC belts is to **turn the system air ON with NO POWER to the logic modules**. This will depress the pressure pans and open up a belt path. Without air, all the rollers are engaged as NBC is a spring-to-drive system and it will be extremely difficult to thread the belt.

**NOTE – Use the slide switch located at the take-up cylinder base to turn the air take-up OFF.**




### Step 2

Disconnect the power to ALL the logic modules (switch off SICK conveyor mounted power supplies). All logic modules lights should be OFF. This will depress the springs in the pressure plan creating a belt path.



### Step 3

Remove bottom guard on drive to have access for belt threading (250-AT30 drive guard shown – the 500-AT bottom guard is a flat plate).




### Step 4

Uncoil the new belt. With the air pressure **ON** the logic, and the logic module power **OFF**, attach a sheet metal splint or the belt threading tool (attached to each drive from factory P/N 1118104) with tape to the end of the belt. This will enhance the ability to thread the belt under the rollers without the ends curling.



### NOTE:

Keep tape smooth and do not apply too much tape, as it will make it difficult to push the belt through the guide rollers.



**NOTE:****a) If replacing an existing belt.**

If replacing a belt determine if the old belt can be pulled through the conveyor. If yes the threading tool will not be needed. Make sure belt path is free from debris.


Duct tape the top and bottom of the old belt end to the new Nitta belt end (thick polyurethane side up) making sure to keep both belts flat and straight, **do not overlap the belts**.

Pull the new Nitta belt through the conveyor. Make sure the Nitta belt is **routed correctly** over all the return pulleys underneath the conveyor (**Always** reference the belt path label on the side of the drive and pull the belt through.). Remove the Duct tape.


Before cutting the belt to length, make sure there is 18" overlap for NBC 250-AT30 and for NBC 500-AT 36" overlap. The overlap is to compensate for belt loss in the finger splice process. Both belt ends must be cut straight.



Tape ends of belts.



Pull Nitta belt through NBC conveyor.



Overlap belt ends.



**b) Nitta belt welding instruction**

MHS Conveyor Nitta Belt Weld Instruction Manual #1120515 – [mhs-conveyor.com](https://mhs-conveyor.com)

MHS Conveyor Nitta Belt Weld Instruction Maintenance Video – [mhs-conveyor.com](https://mhs-conveyor.com)

**Step 5**

Remove rollers at each end and insert the splint with belt attached. Push belt into conveyor. It will be necessary to remove sections of rollers every 30' or 40' to help pull / push the belt through.

**Step 6**

Remove bottom guard for end pulley.

Push belt down between the stationary spacer and 6" dia. end pulley, and up and over the 6" flanged snubber pulley.


Make sure belt passes between ball bearing belt guides and end pulley.






**Step 7**


Pull belt through the bottom side of the conveyor. The belt must be on TOP of the return belt idlers. Wrap the belt end around the drive take-up pulley (250lb manual drive). Wrap the belt end around the drive idler pulley before the air take-up pulley in AT drives.

**Step 8**

**Always** reference the belt path label on the side of the drive and pull the belt through.



250-AT30 (Air Take-up)



500-AT (Air Take-up)

**CAUTION**

- Never field splice the blue urethane belt (MHS Conveyor P/N 1205548) with mechanical lacing, as the belt fabric is not designed to hold lacing.


For more NBC applications MHS Conveyor recommends the following IOM's at: [mhs-conveyor.com](https://mhs-conveyor.com)

MHS Conveyor Also recommends NBC maintenance videos for tracking the NBC belt and NBC belt alignment at: [mhs-conveyor.com](https://mhs-conveyor.com)

## 9.1 THREADING BELT IN NBC TRANSPORTATION CONVEYOR

### Step 1

NBC transportation conveyor is spring to drive with no air. To open a belt path, two Cams under each pressure pan must be rotated to the high side of the Cam.




### Step 2

Thread the belt as shown in steps 3 through 8 of the NBC accumulation conveyor.

### Step 3

Rotate each Cam back to the low side of the Cam re-engaging the spring.



Form more NBC applications MHS Conveyor recommends the following IOM's at: [mhs-conveyor.com](https://mhs-conveyor.com)


MHS Conveyor Also recommends NBC maintenance videos for tracking the NBC belt and NBC belt alignment at: [mhs-conveyor.com](https://mhs-conveyor.com)

## 10 NBC AIR TAKE-UP

### 10.1 500 LB.-AT. AND 250-AT30 DRIVE TENSIONING (AIR TAKE-UP)

#### Step 1

With primary air pressure on and belt installed, slide air shutoff switch forward to engage the air tension on the belt (shown). The belt tension will automatically adjust.



500 LB.-AT Air Sleeve Valve Assembly


#### **NOTE: FOR 250-AT30 DRIVE ONLY (Not Shown)**

The 250-AT30 drive includes a non-adjustable regulator prior to the air shut off slide sleeve.

The accumulation pressure from the conveyor filter regulator (40PSI) is reduced to 30 PSI.


### 10.1.1 Wiring (Optional) Proximity Switch - 500-AT Drive Air Take-up

There is a location for wiring a proximity switch in the air take-up. This can be used to shut off the drive should the belt stretch to the point of bottoming out the take-up or if a belt would break.







### 10.1.2 Wiring (Optional) Proximity Switch - 250-AT30 Drive Air Take-up



## 10.2 NBC CROSS SECTIONS



*NBC accumulation with CRUZchannel rollers low*




*NBC transportation with C6 channel rollers high*


## 11 NBC SKEWING NBC ROLLERS

Skewing rollers is required on NBC if you are using contact accumulation and if the between frame (BF) dimension of your conveyor is double the width of the smallest product. The normal method of skewing is to install a factory skew bed at the charge end of your conveyor. If your conveyor line is over 100' long and you have small product on it, you may want to add a maintenance skew bed midway down the conveyor to preserve the product alignment.

### 11.1 FACTORY SKEW CHARGE SECTION

A standard 12' charge end skew bed is available with factory skewed rollers at 7 degrees. This bed is available in left or right hand. The wheel guard rail is included. This skewed bed will move products across the conveyor about 16" over the 12' length. This side movement is dependent on the bottom condition of the product.





## 12' Skew Bed Installation

MHS Conveyor' dedicated 12' skew bed typically is installed as the first 12' bed section in a NBC conveyor line, starting from the charge end. The rollers are factory skewed to the requested side and the installation is the same as any other NBC intermediate bed section.


A 12' wheeled guardrail is included to prevent the stalling of product as it is forced against the side channel by the skewed rollers. The wheeled guardrail is shipped loose and must be field installed. To install, line up the bolt holes on the guard with the holes in the top flange of the 12' skew bed side channel. The end of the guard and the end of the conveyor bed should be in line.



## 11.2 MAINTENANCE SKEW SECTION

Other than the charge end skew bed, all standard 12' beds have a 4' skew zone designed for the center of the bed. Hole punching in the side channel allow for a  $\frac{3}{4}$ " offset of the rollers over the width of the bed.

**NOTE** that this means wider beds have less of a skew angle than narrow beds and produce a less aggressive skew. **About 2" of movement across the conveyor can be expected per 4' maintenance skew zone on 16" BF conveyor, and 1" of movement on 34" BF conveyor.** A sticker on the conveyor side frame indicates the 4' skew area.



Maintenance skew beds are typically used in contact accumulation NBC lines over 80' which have small product on them. After initial alignment by a charge skew bed, maintenance skew beds keep products aligned. If an NBC conveyor requires maintenance skewing after installation, field skewing of the middle section of a 12' bed is possible. The required skew pressure pan is already included in the middle zone of the standard 12' bed. If product contacts the side channel, a wheel rail should be used.

The steps for field skewing these zones are listed on the following page.

### CAUTION

- Never skew rollers without a skew pressure pan installed. Belt damage will result and warranty will be voided.
- Do not over skew rollers, as it will cause premature belt failure.

### 11.3 FINGER GUARDS FOR SKEWED MAINTENANCE PRESSURE ASSEMBLIES

**NOTE:**

The skew guard is attached to the lower conveyor side channel located on the inside face of the channel on the opposite side of the belt.




*Skew bed guard storage location.*

## 11.4 ROLLER CENTERS 2"

### Step 1

Select the conveyor section in which the rollers are to be skewed. Determine the direction of skew desired and remove one roller from discharge end of the center zone.



#### NOTE:


The bed 4' center zone is the only zone that can be skewed on a 12' intermediate bed.

### Step 2

Install belt guard in 9/32" dia. hole provided. Belt guard provides support of small product at the formation of the skewed zone.




#### Note:



### Step 3

Skew rollers 3/4" to direct the product to the alignment side.



*Right Hand Skew Shown Traveling from Right to Left*


**NOTE:** Rollers may only be skewed a maximum of 3/4" in either direction. One hex hole either side of three hole groups on 3" roller centers.



## 11.5 ROLLER CENTERS 3"

### Step 1

Select the conveyor section in which the rollers are to be skewed. Determine the direction of skew desired. All rollers in the middle zone are used for skewing.




#### NOTE:

The bed center 4' zone is the only zone that can be skewed on a 12' intermediate bed.

### Step 2

Skew rollers  $3/4$ " to direct the product to the alignment side.





#### NOTE:

Rollers may only be skewed a maximum of  $3/4$ " in either direction on the side channel opposite the drive belt.




## 11.6 CRUZ® CHANNEL TO XENOROL® CHANNEL CONNECTIONS




**NOTE:** C6 Channel uses the exact same connections when mounted to XenoROL.

## 11.7 GUARDRAIL MOUNTING ON NBC

NBC can be supplied with rollers low which uses the CRUZ side channel 1 ½" high guardrail. If C6 channel is supplied, any of several height angle guardrail can be used.




CRUZchannel side frame acts as a guardrail



Use 1-1/2" angle for C6 channel guardrail


Use any of several height angle guardrails on C6 channel depending on photoeye placement, and conveyor usage.

For all elevations requiring high guardrail, the NBC is designed to use adjustable guardrail. The configurations and associated part numbers are shown below.



Adjustable guard single high and double high


Flared lead-in section for adjustable channel guardrail.



Use part #117657 at the entrance of all adjustable channel guardrail


## 11.8 CRUZCHANNEL TO C6 NOSE PIECE

A CRUZchannel to C6 nosepiece provides a smooth transition for products moving from rollers high conveyor to rollers low conveyor.



*C6 to CRUZ nosepiece*

## 12 NBC AIR SUPPLY REQUIREMENTS



### General

Every conveyor system is unique, with its own specific requirements. Therefore, the following is a general guide.

### Main Feeder

Air velocity through the main feeder piping can be kept smooth with lower losses using large diameter pipe with minimum bends and restrictions. Standard weight black pipe or copper is suitable for plumbing the compressed air overhead to all points of use.

### Air Drops

MHS Conveyor recommends using at least 3/4" pipe on air drops for high flow and low pressure loss. The drop is terminated with a drain at the bottom. A tee located prior to the drain branches off to the conveyor. This branch line must contain a lockout/shutoff. A shutoff must also be located in the drop before the branch tee. OSHA Rule 29, CFR1910.147 requires energy sources (air drops) be turned off and capable of being locked or labeled with a warning tag.

### NOTE:

The pneumatic system for NBC installations does not require lubrication. Lubrication may affect the valve operation and cause sluggish or erratic operation.

Air drop is a line dispersed from the plant main air header feed.


## CAUTION

- All factory airlines must be thoroughly blown out to clear all debris.
- The regulator must be set at 40 PSI prior to connecting air to NBC.
- If your air compressor uses synthetic oil, a coalescing filter plus a regular filter of 5 micron is required.
- Synthetic oils will shrink the seals in pneumatic devices and valving.

### Low Pressure Switch

## CAUTION

- Loss of conveyor control will occur if air pressure is not maintained.
- A pressure switch is required to be installed into the pneumatic circuit feeding an NBC conveyor system to detect a drop in air pressure below operating limits.
- Conveyor system must be shut-off if low pressure is indicated.



## 12.1 AIR PRESSURE APPLICATION

1. MHS Conveyor supplied pressure regulator is required. (P/N E0034790) Includes: Pop off valve at 45 PSI.
2. Regulator pressure set at 40 PSI. Pressure over 40 PSI can cause permanent damage to the pneumatic actuators.
3. Maximum conveyor length each way from regulator is 100'.
  - a. Locate the regulator in center of conveyor for minimum air pressure drop.
  - b. Conveyors over 200' require additional regulator.
4. Low pressure switch to be set to indicate a pressure drop below 20 PSI.
5. In high humidity or low temperature, use an air dryer.
6. Use 5 micron filter.
7. Lockout/shutoff valve to be provided by air system installer for factory high pressure line before regulator.
8. Low pressure switch is recommended.

### Other:

1. Compressor HP = total CFM ÷ 3.55
2. Air tank size = approx. 1 gallon per CFM

The formulas to determine air consumption follows:



SCFM = .0019 x number of zones x releases per minute for NBC contact accumulation.

## 12.2 AIR REGULATOR LOCK OUT VALVE ON AND OFF POSITION



### NOTE:

- The air regulator valve label details the on and off positions.
- For air pressure regulations please see detailed instruction in this manual.

|                                                                                                    |                                                                                                                                                                                                   |
|----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>WARNING</b> |                                                                                                                                                                                                   |
|                 | <ul style="list-style-type: none"><li>• Do not remove and install sleeve valve to infeed side of regulator. Back feeding through the regulator will cause damage and void the warranty.</li></ul> |



## 13 NBC LOGIC MODULE CONCEPTS

---

### 13.1 CRUZCONTROL® LOGIC

CRUZcontrol is MHS Conveyor accumulation logic package. It utilizes a simple electronic sensor control system providing features that accommodate all accumulation control requirements. This cost-effective logic package is a standard feature of NBC.

It is the intent of MHS Conveyor, through this manual, to provide information that acts as a guide in the installation, operation, and maintenance of MHS Conveyor conveyors featuring CRUZcontrol Logic.

This section of the manual describes basic installation practices, assembly arrangements, preventive maintenance, and assists in replacement parts identification. It is intended for use by personnel who are knowledgeable of installation and safe working practices on conveyor systems.

Not all applications and conditions can be covered; therefore, this information is to be used as a guide only.

### CAUTION

- Add a soft start to all NBC conveyors for speed of 180 FPM and above.
- A controlled speed start-up prolongs belt lacing life at all speeds.

## CRUZcontrol Logic Module Concepts

The CRUZcontrol product line is a set of off the shelf components used to setup accumulation and discharge on NBC conveyor. It consists of logic modules that detect product which control accumulation, function modules that release product, and 24 VDC power supplies. There are also accessories such as sensors and cables to ease installation and interfacing.

CRUZcontrol is a 24 VDC system that will automatically start accumulation when product reaches the end of an accumulation line. When a release signal is applied to a function module that is installed at the discharge end of an accumulation line, the product will begin to release. Product will continue to release until the signal is removed. The type of accumulation that occurs is based on the mode that the logic assembly has been configured for. The type of product release is based on logic assembly mode and function module setup.




Figure 1: Basic Concept Layout

## 13.2 SETTING LOGIC MODULES

After mechanical and electrical installation is complete and there is air to the system, the logic modules may need to be reset.

All logic modules are factory set in the basic mode indicated by the green light. This logic mode may be adequate for your conveyor system. However, if higher product throughput is required, some of the basic modules can be switched to progressive is indicated by amber light.

Never switch all the logic modules to progressive. For maximum product throughput, a pattern of 4 progressive modules and 1 basic module should be followed. See Index heading “Basic and Progressive Logic” for additional explanation.



*Switching logic modes with paper clip*


### CAUTION

- Excessing the 4 to 1 logic rule will cause damage to the belt and void warranty

### 13.3 BASIC AND PROGRESSIVE LOGIC

Every NBC accumulation conveyor is equipped with logic modules that can be switched from basic to progressive logic with a manually activated toggle switch. A green light indicates basic mode and an amber light progressive mode.

The manner in which basic and progressive logic modes change accumulation and release are explained in the following pages.



*Green light indicates basic mode.*




*Amber light indicates progressive mode.*

*Toggle Switch (use paper clip to change)*

### 13.3.1 Basic Logic Operation

Basic Logic functions such that when any two successive photoelectric sensors are blocked, the upstream zone is set to accumulate (stop driving).



In the above example:


- The discharge zone, Zone 6, is shown stopped, signifying that release from the zone is being inhibited and the Zone 6 sensor is blocked.
- When the Zone 6 sensor AND the Zone 5 sensor is blocked Zone 5 will stop running.
- Zone 4 and Zone 3 sensors are not blocked, and the zones are running.
- Zone 2 sensor is blocked, but the zone is running because the Zone 3 sensor is NOT blocked.
- Zone 1 is not driving because both Zone 1 AND Zone 2 sensors are blocked.

#### NOTE:

(Basic Logic) Products being transported on accumulation conveyor are separated by a gap of one zone length upon release. This will reduce the transportation throughput capacity of the conveyor. The rate at which product is introduced onto an accumulation conveyor of this type must not exceed the transportation rate of the conveyor.

### 13.3.2 Discharge from Basic Logic

A release signal given to the Zone 6 Logic Assembly releases product from that zone. As released product clears the electronic sensor, the product stopped at the next upstream zone is driven forward.




This will create a one-zone length gap between all released products; assuming conveyor speeds (accumulation conveyor and downstream conveyor) are identical.

**NOTE:**

If the accumulation logic is set to Slug Release instead of Singulation Release, all affected zones will run, resulting in the release of product with little or no gaps. This overrides the normal Basic Logic function.

**13.3.3 Progressive Logic Operation**

Progressive accumulation functions such that no zones are set to accumulate unless ALL the downstream electronic sensors are blocked, meaning that all downstream zones hold accumulated product.



In the above example, the discharge zone, Zone 6, is shown stopped which is the result of the release from the zone being inhibited (receiving conveyor is stopped) and the Zone 6 sensor being blocked.


Zone 5 sensor not being blocked results in all upstream zones, Zone 1 through Zone 5, running.

**NOTE:**

(Progressive Logic) Products being transported on accumulation conveyor can remain tightly packed, without any gaps being created. The transportation throughput capacity of the conveyor is not reduced due to zoned accumulation.

**13.3.4 Discharge from Progressive Logic**

When the discharge zone, Zone 6, is provided a release signal, all upstream zones also release.



There is no gap between released products; assuming conveyor speeds (accumulation conveyor and downstream conveyor) are identical. The Progressive Logic discharge functions the same as a Slug Release. Initiating the Slug Release will also result in all products releasing, regardless of zone conditions. **In the progressive release mode for contact accumulation, it is extremely important to set every 5th logic module to basic.**

## CAUTION

- CRUZcontrol Logic Assemblies are designed to be fail-safe.
- A loss of module power, a disconnected or severed cable, or a dirty or failed photoelectric sensor will all result in the stopping of a zone, initiating accumulation beginning from the affected zone assuming that air pressure is present.
- With Progressive Logic, failure of a Logic Assembly to function properly could possibly result in product accumulating with zones not stopping as required.
- While this should be unlikely due to the fail-safe nature of the Logic Assembly, the effects of such a failure should be considered. This type of failure could result in excessive line pressure, eventually causing product to push through the discharge zone of the conveyor. Jam detection sensors should be used as appropriate to minimize the effects of such a failure.
- A pressure switch should disconnect conveyor motors from running in a low or no air pressure situation.

## 13.4 APPLICATION – CRUZ® LOGIC

### 13.4.1 Logic Modules and Release Rates

Your NBC conveyor comes with a field switchable logic module for every zone. All the logic modules are shipped in the basic mode. This will be indicated by a green light when the 24VDC power is activated.

### 13.4.2 Basic Release

**In the basic release mode, all logic modules are set to basic.** The release efficiency will generally be 40% to 50% depending on the conveyor speed and the type of release at the discharge of the unit. A timed pulse release is generally more efficient than a one time “flush” type of release.





Diagram of conveyor modes are all set to basic

### 13.4.3 Progressive Release

Conveyors should not be operated with 100% of the logic modules switched to the progressive mode in the contact accumulation mode. This could cause line pressure issues if there is a jam since in the release mode, progressive ignores the photo sensors and dumps all the zones at once, in the same way slug discharge operates. **In the progressive release mode for contact accumulation, it is extremely important to set every 5th logic module to basic.** This limits a product jam, condition line pressure to 16' of conveyor. Failure to set every fifth logic module to basic can result in extreme line pressures that can damage your conveyor, product and could cause injury and void factory warranty.

Release efficiencies in progressive mode (every fifth logic module set to basic) are in the 70% to 90% range depending on speed and type of release at the discharge of the unit.





## CAUTION

- Failures to follow the 4:1 logic module rule will result in voiding the factory warranty.

### 13.4.4 NBC Releasing Accessories

Two items are always required at the discharge end of an NBC accumulation conveyor:

1. A signal to release or accumulate product
2. A method of stopping coasting product (contact accumulation only)



Release function module at discharge end of NBC conveyor part number 1116732


#### *13.4.5 A signal to release or accumulate product*

This is normally a 24V signal from the system PLC to the release function module of the NBC. These Function Modules will accept 115 VAC control inputs. There are some cautions that must be observed to avoid Function Module hardware failure. Part numbers and complete wiring descriptions for release function modules are explained in the NBC® Installation, Operation and Maintenance Manual – item number 1118140.


Exercise extreme caution in activating the slug release line instead of the logic line. If used at all, it should be limited to the discharge 20' or less of conveyor. A slug interrupt cable (item number 1117382) can be used to break this signal where you want the slug release to stop. It should be noted that the same result can be accomplished by switching the discharge logic modules from progressive to basic.

### 13.5 A METHOD OF STOPPING THE COASTING PRODUCT


The following diagrams describe three different methods of stopping coasting products.



For speeds up to 129 FPM, a brake with six coated rollers is sufficient. Standard brake kits are available for NBC.



For speeds from 130 FPM to 230 FPM, a stop is recommended at the discharge end of NBC to stop the coasting product and begin accumulation. Standard stop assemblies are available for NBC. Please note that a stop cannot be allowed to come up under a product. An external PLC controlled sensor must be used to detect a gap and then activate a solenoid to raise the stop.



A belt unit downstream can be used in place of either a brake or a stop. If this belt option is selected, use the CRUZ®belt 4 series.

## 13.6 NBC COMPONENTS

### CRUZcontrol Logic Assembly

The CRUZcontrol Logic Assembly consists of a polarized retro-reflective type photoelectric sensor, pneumatic valve and logic module integrated into one assembly.

The photoelectric sensor will function reliably on conveyor widths up to 34" between frames. The sensor is polarized, and is not affected by shiny surfaces. On NBC applications, the reflector is mounted with a 6 inch offset from the photoelectric sensor, so that the sensor scans across the conveyor on a slight angle.

The sensor bracket as provided allows for easy adjustment of the sensor. An amber LED output indicator on the back of the sensor aids in the adjustment of the sensor. The LED is off if the sensor is not aligned, flashes if functional but marginally aligned, and is on steady if properly aligned. A green LED indicates power on status.




Figure 2: Logic Assembly Mode & Alignment

## Logic Assembly Types

The CRUZcontrol Logic Assembly 1114947 provides an “air to brake” logic output utilizing a normally open pneumatic valve. The pneumatic valve is energized for a zone to be running.

## Logic Assembly Functions

The CRUZcontrol Logic Assembly comes with a momentary button on the front of the housing allowing for selection of either Basic Logic or Progressive Logic mode. A Mode LED indicates either Basic (green) or Progressive (amber) has been selected. Pressing and then releasing the button toggles between the two modes.

Table 1: Logic Assemblies Functions

| Function          | Basic Logic | Progressive Logic |
|-------------------|-------------|-------------------|
| Single Accumulate | Yes         | No                |
| Slug Accumulate   | No          | Yes               |
| Single Release    | Yes         | No                |
| Slug Release      | Yes         | Yes               |

## Logic Assembly Part Numbers

Table 2: Logic Assemblies Part Numbers

| Part Number | Description                                   | Used with             |
|-------------|-----------------------------------------------|-----------------------|
| 1114947     | Basic/Progressive Logic Module, Air to Brake, | NBC straight conveyor |

## 13.7 FUNCTION MODULES

The Function Module provides electrical isolation for external controls and creates controllable zones to facilitate CRUZcontrol applications.

### Function Module Types

There are two different Function Modules, each providing a set of functions: Full Function Module (1116731) and Release Function Module (1116732).

Table 3: Function Module Types

|                         | Single Release | Slug Release | Pulsed Release | Zone Stop | Zone Delay | Logic Interrupt | Slug Interrupt | Zone Status |
|-------------------------|----------------|--------------|----------------|-----------|------------|-----------------|----------------|-------------|
| Full Function Module    | x              | x            | x              | x         | x          | x               | x              | x           |
| Release Function Module | x              | x            |                | x         |            | x               | x              |             |

### Function Module Functions

All directions of upstream and downstream are given with respect to the Function Module. All jumper terminals are on pins 1-2 unless noted otherwise.

Table 4: Function Module Functions

| Single Release |                                                                                                                                                        |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Definition     | Upstream logic line is turned on. The upstream Logic Assembly will release regardless of zone status.                                                  |
| Configuration  | When using TB1; JP3, 1-2 to release the upstream Logic Assembly.<br>When using TB4; JP4, 1-2 to release the upstream Logic Assembly                    |
| User Action    | Apply a high (24VDC/115VAC) signal to TB1, 1-2 if using isolated inputs.<br>Or<br>Apply a high (24VDC) signal to TB4, 3 if using a non-isolated input. |

| Slug Release  |                                                                                                                                                       |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| Definition    | The slug line is turned on. All Logic Assemblies that are connected in one continuous string will release at the same time regardless of zone status. |
| Configuration | When using TB2; JP1, 1-2 and JP2, 1-2 to release all Logic Assemblies.                                                                                |
| User Action   | Apply a high (24VDC/115VAC) signal to TB2, 1-2 if using isolated inputs.                                                                              |



### Pulse Release

|               |                                                                                                                                                                               |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Definition    | Upstream Logic Assembly releases for a length of time set by the ZS ON potentiometer (0-20s) and then accumulates for length of time set by the ZS OFF potentiometer (0-20s). |
| Configuration | When using TB1; JP3, NC to oscillate the release of the upstream Logic Assembly.<br>Adjust ZS ON and ZS OFF potentiometers from 0 to 20 seconds.                              |
| User Action   | Apply a high (24VDC/115VAC) signal to TB1, 1-2 if using isolated inputs.                                                                                                      |

### Logic Interrupt

|               |                                                                                                                                                            |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Definition    | Upstream logic line is turned off. The upstream Logic Assembly is forced to accumulate when it detects a package regardless of the downstream zone status. |
| Configuration | When using TB1; JP3, 2-3 to accumulate the upstream Logic Assembly.<br>When using TB4; JP4, 2-3 to accumulate the upstream Logic Assembly.                 |
| User Action   | Apply a high (24VDC/115VAC) signal to TB1, 1-2 if using isolated inputs.<br><br>Or<br>Apply a high (24VDC) signal to TB4, 3 if using a non-isolated input. |

### Zone Delay

|               |                                                                                                                                                                                        |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Definition    | Delays turning on the upstream logic line. After the downstream zone clears, the upstream Logic Assembly releases, but only after a length of time set by LOGIC potentiometer (0-20s). |
| Configuration | Adjust LOGIC potentiometer from 0 to 20 seconds.                                                                                                                                       |
| User Action   | No action required.                                                                                                                                                                    |

### Slug Interrupt Downstream

|               |                                                                                                                                 |
|---------------|---------------------------------------------------------------------------------------------------------------------------------|
| Definition    | Downstream slug line is disconnected. Logic Assemblies downstream will not slug release when the Slug Release signal goes high. |
| Configuration | JP1, 2-3 all other jumper terminals should be on pins 1-2.                                                                      |
| User Action   | No action required.                                                                                                             |

### Slug Interrupt Upstream

|               |                                                                                                                             |
|---------------|-----------------------------------------------------------------------------------------------------------------------------|
| Definition    | Upstream slug line is disconnected. Logic Assemblies upstream will not slug release when the Slug Release signal goes high. |
| Configuration | JP2, 2-3 all other jumper terminals should be on pins 1-2.                                                                  |
| User Action   | No action required.                                                                                                         |

**Zone Status Indication \***

|               |                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Definition    | Indicates full or empty status of the downstream zone on TB3.                                                                                                                                                                                                                                                                                                                                                                                  |
| Configuration | JP4, 1-2 and JP5, 1-2 for logic status or 2-3 for sensor status, all other jumper terminals should be on pins 1-2.                                                                                                                                                                                                                                                                                                                             |
| User Action   | <p>Connect to TB3 for zone status.</p> <p>The output transition of the Zone Status from OFF to ON or ON to OFF can be delayed by the Zone Status ON and Zone Status OFF Delay potentiometers. This is typically used to indicate a zone is full only after a product is detected for period of time.</p> <p>* On power up there will be a 24s delay on zone status. If the state changes during that period, the delay will be eliminated.</p> |

## 13.8 TERMINAL BLOCK DESCRIPTIONS

Table 5: Terminal Block Descriptions

| Terminal Descriptions |                                                                                                                                                                                                                                                                                              |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| TB1                   | Single release, Logic interrupt Pulse release.                                                                                                                                                                                                                                               |
|                       | <p>This terminal is an isolated input; it must be used when signal voltage is from a supply that is different than the supply powering CRUZcontrol logic assemblies.</p> <p>It can be used when signal voltage is from same power supply that is powering CRUZcontrol logic assemblies.</p>  |
| TB2                   | Slug release.                                                                                                                                                                                                                                                                                |
|                       | <p>This terminal is an isolated input; it must be used when signal voltage is from a supply that is different than the supply powering CRUZcontrol logic assemblies.</p> <p>It can be used when signal voltage is from same power supply that is powering CRUZcontrol logic assemblies.</p>  |
| TB3                   | Zone Status (TB3 only available on full function module)                                                                                                                                                                                                                                     |
|                       | <p>This terminal is an isolated output; it must be used when signal voltage is from a supply that is different than the supply powering CRUZcontrol logic assemblies.</p> <p>It can be used when signal voltage is from same power supply that is powering CRUZcontrol logic assemblies.</p> |
| TB4                   | Inputs                                                                                                                                                                                                                                                                                       |
|                       | <p>This terminal is a non-isolated input; it must be used when signal voltage is from same power supply that is powering CRUZcontrol logic assemblies.</p>                                                                                                                                   |
| TB5                   | Outputs                                                                                                                                                                                                                                                                                      |
|                       | <p>This terminal is a non-isolated outputs; output signal voltage is from same power supply that is powering CRUZcontrol logic assemblies.</p>                                                                                                                                               |

## 13.9 JUMPER DESCRIPTIONS

Table 6: Jumper Descriptions

| Jumper Descriptions |                                                                                                                                                                |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| JP1                 | Downstream slug control                                                                                                                                        |
|                     | Pins 1-2 = slug pass through<br>Pins 2-3 = slug interrupt<br>Pins 3-4 = slug interrupt<br>Pins 4-5 = singulation to slug crossover<br>Pins NC = slug interrupt |
| JP2                 | Upstream slug control                                                                                                                                          |
|                     | Pins 1-2 = slug pass through<br>Pins 2-3 = slug interrupt<br>Pins NC = slug interrupt                                                                          |
| JP3                 | Release control at TB1                                                                                                                                         |
|                     | Pins 1-2 = single release<br>Pins 2-3 = logic interrupt<br>Pins NC = pulsed released                                                                           |
| JP4                 | Release control at TB4                                                                                                                                         |
|                     | Pins 1-2 = single release<br>Pins 2-3 = logic interrupt<br>Pins NC = zone status input (determined by JP5)                                                     |
| JP5                 | Zone Status control (JP5 only available on full function module)                                                                                               |
|                     | Pins 1-2 or NC = downstream logic status<br>Pins 2-3 = downstream sensor status                                                                                |

### 13.10 USE OF 115 VAC CONTROLS

Important information regarding the use of 115 VAC controls:

These Function Modules will accept 115 VAC level control inputs. There are some cautions that must be observed to avoid Function Module hardware failure.

Function Module signal inputs are protected against 500 volt spikes. 115 VAC control signal wiring run in conduit along with higher voltage motor wiring could experience voltage spikes that exceed the 500 volt limit. This can be prevented by running control wiring in separate conduit from motor wiring. Additional protection for the Function Module inputs can be achieved by using an MOV (metal oxide varistor) placed across the input terminals within the Function Module. Suggestions of suitable MOV's would include Panasonic ERZV07D241 or Little fuse V250LA2.

Long conduit runs with motor wiring for multiple motors, and the use of variable frequency drives, all contribute to electrical noise, with a good potential for high voltage spikes. If there is any doubt, the control signals to the Function Modules should be run in conduits separate from motor wiring.

The Function Module signal inputs have high impedance. When connected to some output devices, such as some PLC triac outputs, the inputs could sense an "on" state even if the output connected to it is not on. This can be corrected by adding additional loading to the output. This can be done by adding a loading resistor, placed across the output terminals.

Do not put this resistor inside of the Function Module. The size and wattage rating of the resistor would depend on the output characteristics of the PLC card. A typical value would be 10,000 ohms (10K ohms) and 2 watts. The resistor must be able to dissipate 1.32 watts at 115 VAC, so it will get warm.

## CAUTION

- Do not put this resistor inside of the Function Module. The size and wattage rating of the resistor would depend on the output characteristics of the PLC card. A typical value would be 10,000 ohms (10K ohms) and 2 watts. The resistor must be able to dissipate 1.32 watts at 115 VAC, so it will get warm.

### 13.11 FUNCTION MODULE PART NUMBERS

Table 7: Function Module Part Numbers

| Part Number | Description             |
|-------------|-------------------------|
| 1116731     | Full Function Module    |
| 1116732     | Release Function Module |

Figure 3: Function Modules




Figure 4: Full Function Module Board Layout




Figure 5: Full Function Module Circuit






Figure 6: Release Function Board Layout





Figure 7: Release Function Module Circuit



## 14 NBC POWER SUPPLY REQUIREMENTS

A 24 VDC power supply is needed to power the logic assemblies and the function modules. One power “T” cable is prewired to each power supply. Power supplies are available in 120 VAC or 480 VAC input versions.

### 14.1 POWER SUPPLY REQUIREMENTS

CRUZcontrol operates from a Class 2 power supply voltage of 24 VDC. This limits the total number of CRUZcontrol Logic Assemblies that can be connected to one power supply. There is also a limit on the maximum number of Logic Assemblies that can be in one continuous string, based on the cable length and power requirement of Logic Assemblies. More than one string of Logic Assemblies can be connected to a power supply, as long as the power supply output rating isn’t exceeded.

The Function Modules require 10mA of current at 24 VDC. This needs to be considered, as it will reduce the total number of Logic Modules that can be connected to one Class 2 power supply to a quantity less than stated in Table 8.

| Number of Zones         | Number of Zones |
|-------------------------|-----------------|
| End Tap (95W, 24VDC)    | 27              |
| End Tap (95W, 28VDC)    | 35              |
| Center Tap (95W, 24VDC) | 54              |
| Center Tap (95W, 28VDC) | 46              |

Table 8: Maximum Number of Logic Modules per String – 100/240 VAC

## 14.2 POWER SUPPLY WIRING

### Connection made between two Logic Assemblies using a T Cable

This drawing illustrates a power connection made between two intermediate accumulation zones making use of a “T” Cable. NOTE that all power and control signals, including the Slug and Logic Signals, pass through the “T” Cable uninterrupted.




Figure 8: Two Logic Assemblies using a T Cable

A “T” cable must be installed between two logic module assemblies. Preferably located in the middle of the logic modules connected to the power supply.

### One Power Supply used to power two separate CRUZcontrol sections

This drawing illustrates the use of one power supply to power two separate, short CRUZcontrol sections on two different conveyors. A second "T" cable is required to connect the second CRUZcontrol section to the power supply. This can be done to make better use of the full capacity of a power supply.

It could be necessary to extend the T Cable leads to reach the power supply location. This should be done with a wire gauge large enough to prevent noticeable voltage drop. The number of CRUZcontrol zones that can be connected per string must also be reduced based on the voltage drop of the wire used.

The brown lead on the "T" Cable connects to +24 VDC on the power supply. The blue lead on the "T" Cable connects to 0 VDC on the power supply.




Figure 9: Two Separate CRUZcontrol Sections

### Using two Power Supplies to power one extended CRUZcontrol section

A CRUZcontrol string with more than 54 Logic Assemblies would require the use of more than one power supply. This can be done, but it requires that the power supplies be isolated from each other at the +24 volt line. This drawing illustrates how to isolate the two strings making use of a Power Interrupt Cable. The + VDC line is not passed through, while the Slug Release and Singulation Release Signals as well as OVDC are connected to pass the signals through uninterrupted.




Figure 10: One CRUZcontrol Section with Two Power Supplies

### Power Supply Part Numbers

| Part Number                |         | Description                                               |
|----------------------------|---------|-----------------------------------------------------------|
| Kit Part Number<br>1117431 | 1117972 | PWS, 24VDC,3.9A,120VAC, NBC CLASS 2, W/ 2X2 T-CABLE       |
|                            | 1117937 | BRKT, POWER SUPPLY,SICK NBC                               |
| Kit Part Number<br>1117432 | 1107030 | PWS, 24VDC,3.8A,480VAC, NBC ,2 PH, CLASS 2, W/2X2 T-CABLE |
|                            | 1117937 | BRKT, POWER SUPPLY,SICK NBC                               |
| Cables                     | 1117379 | CABLE,CTRLS-T_CABLE-79"-2X2-FLYING LEADS                  |
|                            | 1117380 | CABLE,CTRLS-POWER INTRPT-2X2                              |

Table 9: Power Supply Part Numbers

## 14.3 ACCESSORIES

### Auxiliary Photoelectric Sensor

There is often a need to sense product presence on a CRUZcontrol equipped conveyor, with the sensors connected to a control system other than CRUZcontrol. To allow for this, adequate space has been provided alongside of the CRUZcontrol photoelectric sensors to allow for the mounting of a second independent photoelectric sensor, sharing the same holes through the conveyor side channels and the same reflector. Appropriate holes are provided for the photoelectric sensor mounting bracket. The discharge end of NBC conveyor is also provided with an additional mounting location for a photoelectric sensor and reflector.

The following kits are available, which include the photoelectric sensor and appropriate bracket. Even though not normally needed, an extra reflector and adhesive mounting tape is also included with each kit.

The 10-30 VDC photo sensors are similar to the CRUZcontrol sensors. They are light operate, with a 50 mA maximum output current, and come with a 27" cable (no connector).

| Part Number | Description                                                                |
|-------------|----------------------------------------------------------------------------|
| 1117727     | PE, ASY SICK ZL PNP LIGHT OP 700MM LEAD W/ FLYING LEADS W/REFLECTOR & TAPE |

Table 10: Photoelectric sensor

### Reflector

Replacement reflectors can be ordered with the following part number.

| Part Number | Description                     |
|-------------|---------------------------------|
| 400004      | PE, REFLECTOR 4-3/8" X 1-1/8"   |
| 1153640     | TAPE, FOAM DBL SIDED 3/4"SQUARE |

Table 11: Reflector

### Sensor Valve Assemblies

A Sensor Valve Assembly is used for applications not requiring accumulation logic, (controlling the zone with a PLC) but the solenoid valve and photoelectric sensor configuration as used in the CRUZcontrol channel is still desired.

| Part Number | Description                                       |
|-------------|---------------------------------------------------|
| 1116736     | LM, CRUZCONTROL SENSOR/VALVE W/ZL2 EYE,N.O. VALVE |

Table 12: Sensor Valve Assembly

## Extension Cables

The following extension cables are available to meet application requirements where longer zone lengths or skipped zones must be accommodated. Each cable has 4 conductors, with male and female 2X2 connector ends.

| Part Number | Description                          |
|-------------|--------------------------------------|
| 1117372     | CABLE,CTRLS-EXT-39"-2X2 MALE-FEMALE  |
| 1117373     | CABLE,CTRLS-EXT-78"-2X2 MALE-FEMALE  |
| 1117374     | CABLE,CTRLS-EXT-157"-2X2 MALE-FEMALE |

Table 13: Extension Cables


## Discharge Logic Control

Discharge Logic Control refers to using a standard Logic Assembly set to Basic Logic mode to control the release from the last discharge zone of a length of CRUZcontrol. This is typically done when CRUZcontrol conveyor (of any kind) feeds non-CRUZcontrol conveyor. There are no air connections made to the valve section of the Logic Assembly. When used this way, the added Logic Assembly is known as the Discharge Logic Assembly (DLA).

The Discharge Logic Assembly is mounted on the charge end of the conveyor immediately downstream of the last (discharge) zone of a length of CRUZcontrol accumulation conveyor. It is connected to the Logic Assembly of the discharge zone as shown. There is no need for a Function Module to be attached to it. The DLA does not need to be given a release signal. Product blocking that photoelectric sensor will stop release from the CRUZcontrol discharge zone, until the photoelectric sensor clears again. This operation can usually be left enabled and ready to function regardless of whether the receiving conveyor is running or off. There would be no need to interface the CRUZcontrol operation with the receiving conveyor operation, since the functioning of it is based solely on product movement.



Figure 11: Discharge Logic Control



The following hardware listing is for two Discharge Logic Assembly kits consisting of the Discharge Logic Assembly, a reflector, and mounting brackets. The mounting brackets provide for the mounting of the Discharge Logic Assembly and reflector either ½" or 3" above a standard CRUZ side channel. Since every application is different, there will usually be a need to drill mounting holes for the brackets.

Table 14: Discharge Logic Assembly

| Part Number | Description                                                             |
|-------------|-------------------------------------------------------------------------|
| 1117859     | KIT, NBC DISCHARGE LOGIC 1/2" TOR<br>(½ inch above rollers scan height) |
| 1117860     | KIT, NBC DISCHARGE LOGIC 3"TOR<br>(3 inch above rollers scan height)    |

## 15 CRUZCONTROL ON SITE INSTALLATION

---

### Pre-installed on the conveyor

- The CRUZcontrol Logic Assemblies are installed on the side channel of the conveyor bed.
- The air supply tubing (3/8" OD X 1/4" ID) for the conveyor is plumbed along the length of the conveyor bed, passing through each Logic Assembly.
- The zone control air is plumbed (1/4" OD X .160" ID) from the Logic Assembly to the zone air pucks or cylinders.
- The photoelectric sensors are mounted for each zone, along with the reflector across the conveyor bed. The photoelectric sensors are tested to insure proper alignment with the reflectors, as well as proper functioning of the Logic Assemblies.

### Field Installation


Bed to bed connections:

- Connection of air supply tubing between conveyor beds, terminating the ends of the air supply tubing
- Connection of the Logic Assembly upstream or downstream cable from the last zone of a conveyor bed to the first zone in the next upstream conveyor bed

### System connections

- Connecting the air supply to the conveyor
- Connecting a power supply into the string of Logic Assemblies
- Adding extension, power interrupt, or adapter cables if needed
- Adding auxiliary photoelectric sensors as required for lead zone and "line full" conditions
- Providing a release signal to the function module at the discharge zone

Figure 12: Logic Assembly



## 16 CONVEYOR FLOW

The logic assembly wiring is “in-line” for left hand flow conveyors; for right hand flow conveyors the wiring direction will be reversed. Cables will cross under the logic module assembly.

Figure 13: Left Hand Flow Conveyor Bed





Figure 14: Right Hand Flow Conveyor Bed



### Example 1: Releasing from CRUZcontrol

| Releasing from CRUZcontrol |                                                                                                                                                                                                                                          |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Problem                    | Releasing Accumulated Product                                                                                                                                                                                                            |
| Solution                   | When using CRUZcontrol the product will automatically accumulate.<br>A signal must be given to the function module to get it to release.                                                                                                 |
| Configuration              | Plug Function module into discharge zone.<br>All jumpers are set to pins 1-2.<br>Give function module a release signal either through the isolated input as shown in Figure 15 or through the non-isolated inputs as shown in Figure 16. |
| Operation                  | Product will release for as long as the release signal is given.                                                                                                                                                                         |

Figure 15: Isolated Input Single Release





Figure 16: Non-Isolated Input Single Release



### Example 2: Creating a work zone

| Creating a work zone |                                                                                                                                          |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| Problem              | Creating a work zone in the middle of a section of CRUZcontrol                                                                           |
| Solution             | Use the release function module and interrupt the downstream logic to start accumulation.                                                |
| Configuration        | When using TB1 to interrupt the logic set jumper terminal JP3, 2-3<br>When using TB4 to interrupt the logic set jumper terminal JP4, 2-3 |
| User Action:         | Apply a high signal to TB1 (24Vdc/120Vac) or TB4 (24Vdc)                                                                                 |
| Operation            | All product stops at a specific accumulation zone, when the contact is closed and is released when the contact is opened.                |

Figure 17: Work Zone




Figure 18: Work Zone Using TB





Figure 19: Work Zone Using TB1 4





Example 3: NBC accumulation release to conveyor


| <b>NBC-C accumulation release to feed induction conveyor</b> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Problem                                                      | Creating line pressure when feeding a slower conveyor                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Solution                                                     | Use logic assembly as a discharge logic assembly                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Configuration                                                | Place Discharge Logic Assembly (DLA) downstream of conveyor discharge zone.<br>Set mode to basic. Do not plumb airline to logic assembly.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| User Action:                                                 | None needed.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Operation                                                    | The Discharge Logic Assembly is connected to the Logic Assembly at the discharge end of the NBC conveyor. There is no need for a Function Module to be attached to it. The DLA does not need to be given a release signal. Product blocking that photoelectric sensor will stop release from the NBC discharge zone, until the photoelectric sensor clears again. This operation is left enabled and ready to function regardless of whether the induction conveyor is running or off. There is no need to interface the CRUZcontrol operation with the induction conveyor operation, since the functioning of it is based solely on product movement. |

NBC conveyor, when accumulating and subsequently releasing accumulated product, will result in some amount of line pressure at the discharge end of the conveyor. This is caused by the momentum of moving product coasting to a stop as it accumulates.

### Example

The NBC is running at 180 FPM, feeding the induction conveyor section prior to a pick zone module diverter. Without proper control of the discharge from the NBC, cartons released to the induction conveyor could possibly overdrive it and push past the 90 FPM section onto the 180 FPM section, not permitting product gapping to occur as required for the diverter to function properly.


The mounting location of the Discharge Logic Assembly photoelectric sensor and the reflector will determine release performance. A good starting point would be to locate the photoelectric sensor 12" downstream from the charge end of the induction conveyor, and the reflector 18" downstream from the charge end. The final locations should be determined based on system performance.



Example 4: Product Gapping

The following describes a technique, using CRUZcontrol, which creates a gap in a train of moving product. In the situation described, the gap is used to allow for the raising of a product stop. This would apply primarily to the progressive mode of accumulation control, which accumulates and discharges from accumulation with only minimal gaps between products.

The following illustrates an NBC accumulation lane used to release product to a merge conveyor. A Product Stop is located at the end of the accumulation lane, controlled by the solenoid valve as shown. The last two accumulation zones are also provided with brakes, as shown. These brakes are controlled by the CRUZcontrol Logic Assemblies that also control the zone drive. Also shown just prior to the Product Stop is a Product Present Photosensor.



## Operation

The Product Present Photosensor is connected to a PLC (programmable logic controller). The Photosensor is used to sense if product is accumulated behind the Product Stop, ready to be released. The Photosensor is also used to sense a gap in the flow of product adequate enough to raise the Product Stop after releasing product from the lane.

The Product Stop is solenoid activated, and controlled by the PLC. The stop is lowered by energizing the solenoid.

**Function Module #1** (a Release Function Module) is configured and wired for Singulation Release operation. (Refer Table 4). The signal provided to the Product Stop solenoid is also connected to Function Module #1.

When the Product Stop is raised (solenoid and Function Module not energized), product blocking the Photosensor of the CRUZcontrol Logic Assembly will result in the conveyor zone going into accumulation and the zone brake being activated. This in turn enables accumulation beginning with the next upstream accumulation zone, once the Photosensor in that zone is blocked.

**Function Module #2** (also a Release Function Module) is configured and wired for Logic Interrupt operation (Refer to Table 4). When it receives a signal (from the PLC), it passes the logic signal from the downstream accumulation zone to the upstream accumulation zone. Accumulation and release function normally, as if there no Function Module installed.

To create a gap in the flow of product, the PLC signal to Function Module #2 is turned off. This puts the zone upstream of Function Module #2 into accumulation mode, once its Photosensor is blocked. The brake in the zone is also set whenever the zone is set to accumulate.

## 16.1 OVERVIEW – MHS CONVEYOR CRUZCONTROL LOGIC MODULE

This section describes the development requirements for the MHS Conveyor CRUZcontrol logic module to be used with NBC. The new modules will be a complete solution that controls product flow through either “basic” and “progressive” accumulation with single or slug release. “Basic” accumulation may also be described as single accumulate where product detection in two consecutive zones will cause the upstream zone to accumulate. “Progressive” accumulation is also known as slug accumulate, which stops flow at the furthest downstream zone when product is detected.

A CRUZcontrol module will be mounted at each conveyor zone and connected in series with the neighboring upstream and downstream zones. The CRUZcontrol module will be comprised of a retro-reflective sensor, logic module with integrated pneumatic valve, and daisy chain connections. The retro-reflective sensor attached to the CRUZcontrol module will be located in the same zone (local zone) as the CRUZcontrol module and the valve will control the local zone.

### 16.1.1 Conveyor Details

Table 15: Conveyor Specification

|                        |                                                                      |
|------------------------|----------------------------------------------------------------------|
| Width (BF)             | 16 in. (400mm), 22 in. (550mm), 28 in. (700mm), 34 in. (850mm)       |
| Zone Length            | 48 in. (1219mm)                                                      |
| Roller Diameter        | 1.9 in. (48mm)                                                       |
| Roller Pitch           | 2.0 in. (76 mm), center to center, 3.0 in. (114 mm) center to center |
| Reflector Hole Size    | 13/16 in. x 1-9/16 in. slot                                          |
| Sensor Skew            | 6.0 in. (150mm), maximum                                             |
| Steel Thickness        | 12 Gauge                                                             |
| Pneumatic Type         | Air to Brake                                                         |
| Working Air Pressure   | 40 PSI, maximum                                                      |
| # of Pucks per Zone    | 2                                                                    |
| Minimum Product Height | 0.5 in. (12.7mm)                                                     |

Figure 20: MHS Conveyor CRUZ-Channel





Figure 21: Logic Module Wiring for over molded 2x2 Daisy Chain Cables



### 16.1.2 Description of Logic

Two accumulate modes will be selectable on the module and two release modes will be available via wiring. Their operation is described below. NOTE that both single and slug release is available in basic mode while progressive mode will only slug release due to the logic (refer to Table 20).


Table 16: Logic Function

| Function          | Basic Logic | Progressive Logic |
|-------------------|-------------|-------------------|
| Single Accumulate | Yes         | No                |
| Slug Accumulate   | No          | Yes               |
| Single Release    | Yes         | No                |
| Slug Release      | Yes         | Yes               |

### Basic Accumulation Module

In accumulation, any two consecutive sensors detecting product will cause the upstream zone of the two consecutive zones to deactivate until the downstream zone is no longer detecting product. The logic signal is passed upstream on Pin 2.

Figure 22: Basic Accumulation Logic




For single release, a given zone will release once the sensor in the downstream zone is clear of product. This may be done by removing product or applying an electrical release signal (+VDC) to PIN 2 and this also applies to the discharge zone.

When using slug release, all zones to which the slug line is connected will be activated simultaneously. This is initiated by applying supply voltage to PIN 4.

### Progressive Accumulation Module

In accumulation, a zone will not deactivate until the furthest downstream sensor is detecting product and deactivates. The next upstream zone will then become the furthest downstream zone and deactivate when the sensor is blocked. The logic signal is passed upstream on PIN 2.

Figure 23: Progressive Accumulation Logic



Progressive mode only allows slug release. All zones to which the slug line is connected will be activated simultaneously. This is initiated by applying supply voltage to PIN 4. The same effect may be achieved by applying an electric release signal (+VDC) to PIN 2.

### Pneumatic Valve

The pneumatic valve shall be embedded in the logic module housing and satisfy the requirements outlined in Table 20.

Table 17: Pneumatic Valve Specification

|                          |                                  |
|--------------------------|----------------------------------|
| Operating Pressure Range | 0-40 PSI (0-2.75 bar)            |
| Flowrate Capacity        | ≥ 0.04 Cv (40 NI/m)              |
| Ventilation Capacity     | ≥ 0.04 Cv (40 NI/m)              |
| Power Consumption        | 1W                               |
| Minimum Supply Voltage   | 19.2 VDC                         |
| Maximum Supply Voltage   | 27.6 VDC                         |
| Duty Cycle               | 100%                             |
| Life Expectancy          | 100 million cycles               |
| Input Air Connection     | 3/8 in. (9.5mm) barbed fitting   |
| Output Air Connection    | 1/4 in. (6mm) barbed fitting     |
| Operating Mode           | N.O. (Air to Brake)              |
| Air supply               | Non-lubricated, 5 micron or less |


#### 16.1.3 Sensor/Valve Assembly

The Sensor/Valve Assembly module differs from the standard module in that it does not have a female cable connection, does not connect to a neighboring module, does not contain logic, and has a unique wiring scheme on the male connection. This module may be simply described as a junction box with connection to provide +VDC to the sensor and valve, sensor output to the PLC, and valve input from the PLC. The male connection interface will be a cable with flying leads and have two meter (2m) length. The jacket shall be stripped and conductors perforated. See the current Sensor/Valve Assembly, E0006229, for reference.

#### 16.1.4 M12 Sensor Connection used with WTR style sensors

The M12 Sensor Connection module differs from the standard module in that it does not have the sensor hard wired to the module. Instead, a cable with female M12 connector will be provided for connection with standard sensors (i.e. WTR style sensors). This connection will have a 28 in. (711mm) length and right angle connector. The module requires a PNP sensor input signal that is either Light Operate from a retro-reflective sensor or Dark Operate from a proximity sensor. Pin-out may be found in Figure 30.

Figure 24: M12 Sensor Connection Pin-out



#### Adaptor Cable for M12 Connector

To connect the M12 logic module or M12 WTR sensor, a conversion cable is required. The adaptor cable allows the M12 connector to plug into the 2x2 connector. See Table 21 for types.



# 16.2 POWER SUPPLY

A variant of the CRUZcontrol power supply shall be developed with 2x2 connectivity and be UL Listed as Class II. Two input power options will be available:

- 115/230 VAC, single-phase
- 480 VAC, two (2)-phase supply

## Cables

Application specific cables will be necessary in certain cases. A list of necessary components may be found below, NOTE that male refers to a male housing on 2x2 connections while female refers to a female housing; See Part Number Listing Table 19 Accessories w/2 Connections

Figure 25: “T”-Cable Wiring




Figure 26: Power Interrupt Wiring




Figure 27: Logic Interrupt Wiring





Figure 28: Slug Interrupt Wiring



### 16.2.1 Conveyor Power Supply

MHS Conveyor's power supplies feature a compact housing design that is designed specifically for use with CRUZcontrol logic modules.

These units meet the latest NEC Class II requirements in accordance with UL, EN, IEC standards. Installation is fast and easy due to slotted holes in a durable mounting plate that mounts directly to the side of the conveyor.

The power supplies are also capable of buffering brief power failure conditions at rated voltage (e.g. 20 ms at 120 VAC) in accordance with EN 60204-1. Global acceptance is also achieved by conformance with cULus standards (North American compliance) and CE standard requirements (European compliance).

#### Power Supply Features

- Adjustable output voltage up to 24...28 VDC
- 115/230 VAC or 480 2 phase VAC input
- State-of-the-art design
- Type 1 enclosure, IP 20
- Bolt on mounting

Figure 29: MHS Conveyor P/N 1117432 Dimensional Diagrams




Figure 30: MHS Conveyor P/N 1117432 Connection Diagrams




Figure 31: MHS Conveyor P/N 1117431 Dimensional Diagram





Figure 32: MHS Conveyor P/N 1117431 Connection Diagram



### 16.2.2 Power Supply Technical Data

| Technical Data                                          | PN 1117431                                              | PN 1117432               |
|---------------------------------------------------------|---------------------------------------------------------|--------------------------|
| <b>Input Parameters</b>                                 |                                                         |                          |
| Input Voltage Range V AC (nominal)                      | 100...120/220...240 V                                   | 380...480 V (2 phase)    |
| Input Voltage Range V AC (continuous)                   | 85...132/184...264 V                                    | 323...552 V (2 phase)    |
| Input Frequency                                         | 47...63 Hz                                              | 47...63 Hz               |
| Phase                                                   | 1                                                       | 2                        |
| Input Voltage Range V DC (see derating requirements)    | 220...375 V                                             | consult factory          |
| Input Rated Current                                     | < 2.0 A (100 V AC)                                      | < 0.42 A (400 V AC)      |
|                                                         | < 0.95 A (196 V AC)                                     | < 0.36 A (480 V AC)      |
| Transient Immunity Over Entire Load Range               |                                                         | Consult factory          |
| <b>Output Parameters</b>                                |                                                         |                          |
| Output Voltage                                          | 24...28 V DC                                            | 24...28 V DC             |
| Output Voltage Preset                                   | 24.5 V DC ±0.5%                                         | 24.5 V DC ± 0.5%         |
| Ripple/Noise @ 20 MHz, 50 Ohm                           | < 50 mVpp                                               | < 50 mVpp                |
| Output Voltage Regulation Accuracy                      | 0.5% Vout static                                        | ± 200 mV static          |
|                                                         | ±1.5% Vout dynamic                                      | Dynamic not available    |
| Output Rated Current                                    | 3.9 A (at 24 V)                                         | 3.75 A (at 24 V)         |
|                                                         | 3.2 A (at 28 V)                                         | 3.2 A (at 28 V)          |
| Hold Up Time                                            | > 20 ms (196 V AC, 24.5V/3.9 A)                         | Typ. 52 ms (at 400 V)    |
|                                                         | > 20 ms (100 V AC, 24.5 V/3.9A)                         | Typ. 93 ms (at 480 V)    |
| <b>General Device Parameters</b>                        |                                                         |                          |
| Operating Temperature Range (Tamb) - Full Load          | 14...140°F (-10...60 C)                                 | 14...140°F (-10...60 C)  |
| Operating Temperature Range (Tamb) - Derated            | 122...140°F (50...60 C)                                 | 122...140°F (50...60 C)  |
| Storage Temperature                                     | -13...185°F (-25...85 C)                                | -13...185°F (-25...85 C) |
| Humidity (Do not energize when condensation is present) | < 93%                                                   | < 95%                    |
| Input Cable Access                                      | 3/4 or 1/2 in. hole for conduit                         |                          |
| AC Connection Wires                                     |                                                         |                          |
| Stranded cable                                          | 0.3...2.5 mm2 / AWG 28-12                               | ≥ 2,5 mm2 , AWG 26-12    |
| Solid cable                                             | 0.3...4 mm2 / AWG 28-12                                 | ≥ 2,5 mm2 , AWG 26-12    |
| Stripping at wire end                                   | 6 mm                                                    | 6 mm                     |
| <i>Note: secure wires from strain</i>                   |                                                         |                          |
| AC External Protection/Fusing                           | 20A Max                                                 | 30A Max                  |
| Output Connector Cables                                 | M12 4-pin "T" cable                                     | M12 4-pin "T" cable      |
| Efficiency                                              | 90% (typical at 230 V AC, 3.9A)                         | 89.5% (at 400 V)         |
|                                                         |                                                         | 89.0% (at 480 V)         |
| Protection Class - Type 1 Enclosure                     | IP 20 (DIN/IEC 60 529)                                  | IP 20 (DIN/IEC 60 529)   |
| MTBF                                                    | 500,000 h @ 40C SN 29500                                | 1.5 Mio h @ 40C SN 29500 |
|                                                         | Not tested at MIL 217 GP40                              | 482,000 h @ MIL 217 GP40 |
| Dimensions                                              | 9.25 x 5.67 x 5.13                                      | 9.25 x 5.67 x 5.13       |
|                                                         | (235 x 144 x 130.4 mm)                                  | (235 x 144 x 130.4 mm)   |
| Weight                                                  | 3.9 lbs (1.8 kg)                                        | 4.4 lbs (2.0 kg)         |
| Cover Screw Torque Rating (in-lb)                       | 4±1                                                     | 4±1                      |
| Mounting                                                | Vertical mounting only. AC input enters from the bottom |                          |
| Clearance                                               | Keep 4 in. clearance from ventilating slots in cover    |                          |
| <b>Applicable Standards</b>                             |                                                         |                          |
| EN 60 950-1, IEC 60 950                                 | Yes                                                     | Yes                      |
| EN 60 204-1, EN 50 178                                  | Yes                                                     | Yes                      |
| <b>Third Party Approvals</b>                            |                                                         |                          |
| UL 508 Listing (US and Canada)                          | Multiple Listing                                        | Multiple Listing         |
| UL 60 950-1 Recognition (US and Canada)                 | Multiple Listing                                        | Multiple Listing         |
| NEC Class 2 According to UL 1310                        | Multiple Listing                                        | Multiple Listing         |

### 16.2.3 Part Number Listing

Table 18: Logic Module w/Sensor and 2x2 Daisychain

| MHS Conveyor Part # | Description                                    |
|---------------------|------------------------------------------------|
| 1114947             | Basic/Progressive, AtoB                        |
| 1116736             | Sensor/Valve Assembly, N.O. Valve              |
| 1116737             | Basic/Progressive, AtoB, M12 Sensor Connection |

Table 19: Accessories w/2x2 Connections

| MHS Conveyor Part #           | Description                                                                                              |
|-------------------------------|----------------------------------------------------------------------------------------------------------|
| 1117370                       | Male Cordset                                                                                             |
| 1117371                       | Female Cordset                                                                                           |
| 1117372<br>1117373<br>1117374 | Extension Cable, male-female, 1m<br>Extension Cable, male-female, 2m<br>Extension Cable, male-female, 4m |
| 1117375                       | 2x2-M12 Adapter, female-female                                                                           |
| 1117376                       | 2x2-M12 Adapter, male-male                                                                               |
| 1117377                       | 2x2-M12 Adapter, female-male                                                                             |
| 1117378                       | 2x2-M12 Adapter, male-female                                                                             |
| 1117379                       | T-Cable (with flying leads), 2m                                                                          |
| 1117380                       | Power Interrupt Cable                                                                                    |
| 1117381                       | Logic Interrupt Cable                                                                                    |
| 1117382                       | Slug Interrupt Cable                                                                                     |
| 1116731                       | Function Module, Full                                                                                    |
| 1116732                       | Function Module, Release                                                                                 |
| 1116733                       | Function Module, Zone Status                                                                             |

Table 20: Logic Module w/MHL1 Sensor and M12 Daisychain for CRUZcontrol

| Part #    | Description                       |
|-----------|-----------------------------------|
| E0001900A | Basic, AtoB                       |
| E0001901A | Basic, AtoD                       |
| E0001904A | Progressive, AtoB                 |
| E0001905A | Progressive, AtoD                 |
| E0005546  | Basic, No Valve                   |
| E0006229  | Sensor/Valve Assembly, N.O. Valve |

Table 21: Accessories w/M12 Connections for CRUZcontrol

| Part #   | Description                 |
|----------|-----------------------------|
| ZPI-P1   | Power Isolation Cable       |
| ZLSI-P4  | Slug Interrupt Cable        |
| E0006304 | Function Module, Full       |
| E0006305 | Function Module, Release    |
| E0003613 | Singulation Interrupt Cable |

## 17 NBC MAINTENANCE & TROUBLESHOOTING

---

### 17.1 GENERAL PREVENTIVE MAINTENANCE



Periodic maintenance intervals shown may vary with load, speed, hours of daily operation, ambient temperature, humidity, etc. Intervals can be established by fairly frequent maintenance at first; then lengthen the intervals as justified by observation of need based on history. The following is based on 5 days per week, 8 hours per day under normal conditions.

#### Daily

- Listen to everything for unusual noises or vibration.
- Visually inspect to see that conveyor sections are clear and free of debris.
- Check to see that all safety guards are in place.
- Check any oil leakage.
- Check for loose bolts or parts.
- Check air filter bowls for accumulated water.
- Listen for air leaks.

#### Weekly

- Check belt tracking
- Inspect bearings and gearmotors for excessive noise or heat.
- Check operation of all electrical controls.
- Check for proper PSI on air regulators.

|                                                                                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>WARNING</b> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|                 | <ul style="list-style-type: none"><li>• Prohibit riding on conveyor by anyone.</li><li>• Think before making any adjustments. It may prevent an injury. Remember, all moving components are potentially dangerous.</li><li>• Protect yourself from unexpected starts when working on a stopped unit by locking and tagging the control panel or disconnect switch that supplies power to the unit.</li><li>• Lockout/Tagout procedures must be followed for every energy source of the conveyor.</li></ul> |



### Monthly

- Check air filters for cleanliness.
- Check drive unit for leaking seals and oil level in the gear case (if applicable), unusual noises, vibration, and stress cracks.

### Semi-Yearly

- Inspect and clean motor control centers.
- Grease re-greasable bearings. *Recommend NLGI #2 lithium complex grease.*
- Check the belt welded splice for signs of early failure.

### Yearly

- Inspect oil in gearboxes.
- Inspect tightness of all nuts and bolts on units. Re-adjust and, if necessary, re-tighten.
- Check for plumb and level. Shims have been known to vibrate out from under supports in isolated incidents.
- Touch up paint that has been chipped. Unpainted surfaces will rust.
- Inspect for stress/fatigue cracks in frame and supports.

### Welded Belt Splice Inspection

- Belt splice should be inspected every 2,000 hours.
- If belt splice is cracked or coming apart it should be scheduled as soon as possible for a new belt splice to replace the old belt splice.

## CAUTION

- Check to confirm tools and foreign objects have not been left on or inside the conveyor.
- Check to confirm all loosened parts have been retightened.
- Check to confirm all guards have been installed.
- Never re-weld over old belt splice. This makes the belt splice weak and brittle.

### Gearmotors



- NBC drive units use gearmotors which are properly filled at the factory with sufficient lubrication for their mounting position.
- A synthetic lube is the standard lube supplied. Refer to manufacture for details.

### Disassembly/assembly procedure as follows

1. Remove necessary guards to access maintenance areas.
2. Disconnect any electrical connection.
3. Remove gearmotor.
4. Perform required maintenance.
5. Reverse procedures for assembly.
6. Replace all guards.



### Regularly inspect all gearmotors to guarantee maximum performance.

1. Tightness of bolts and screws.
2. No major oil leaks.
3. No excessive heating.
4. No unusual vibration or noise.

|  <b>WARNING</b> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               | <ul style="list-style-type: none"> <li>Do not perform maintenance on the conveyor until the startup controls are locked out and cannot be turned on by any person other than the one performing the maintenance.</li> <li>If more than, one member of a crew is working on the conveyor, EACH CREW MEMBER MUST HAVE A LOCK ON THE POWER LOCK OUT.</li> <li>The air pressure must be turned off to the work area.</li> <li>All pneumatic devices must be de-energized to prevent accidental cycling of the device.</li> </ul> |

### Solenoid Valves

In order to minimize downtime, it is normally not feasible to repair malfunctioning electrical or valve components while leaving the conveyor unusable. Spare components should be kept in stock for emergency replacement. If feasible, the part may be repaired later to replace maintenance stock. Items which cannot be readily repaired or are questionable should be replaced. Components under warranty should not be repaired except in an emergency.

|  <b>WARNING</b> |                                                                                                                                                                                                       |
|----------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                 | <ul style="list-style-type: none"> <li>Before removing a valve or other pneumatic component, shut off and exhaust the entire pneumatic circuit and shut off and lockout electrical supply.</li> </ul> |

## Sensing Switches

Sensing switches are of two types:

- retroreflective photoeye
- proximity switch

### Adjust the retroreflective type as follows

1. Determine what sizes of target the photoeye must sense
2. Adjust for the worst case, usually smallest item, by loosening photoeye mounting nut and aligning while making sure photoeye has unobstructed view of reflector.
3. Move the target in and out of the field of detection to ensure that the photoeye energizes and de-energizes.

### Adjust the proximity type as follows

1. Loosen proximity switch mounting bolt and adjust sensing switch so that the product passes directly in front of the switch face, as close to the switch face as possible without making contact.
2. Check that the proximity switch energizes and de-energizes as the product passes in front of the switch face
3. Tighten the mounting bolt

## 17.2 TROUBLESHOOTING GUIDE – MECHANICAL/ELECTRICAL

| Mechanical Problem                         | Possible Cause                         | Remedy                                                                                                                                                                        |
|--------------------------------------------|----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Insufficient drive                         | Rollers not turning consistently       | Check alignment of pressure pan                                                                                                                                               |
|                                            | Poor bottom on product                 | Improve product convey ability                                                                                                                                                |
|                                            | Overloading of product                 | Remove overload                                                                                                                                                               |
|                                            | Belt slippage                          | Check air pressure on take up assembly. Make sure belt tension is proper.                                                                                                     |
|                                            | Drive belt interference with structure | Locate and correct interference                                                                                                                                               |
|                                            | Belt installed wrong                   | Install belt properly                                                                                                                                                         |
| Rollers not turning/turning slowly         | Belt not engaged with roller           | Check alignment of pressure pan                                                                                                                                               |
|                                            | Zone not active                        | Check alignment of downstream photo eye                                                                                                                                       |
|                                            | Interference with roller or belt       | Locate and correct interference                                                                                                                                               |
|                                            | Bent roller                            | Replace roller                                                                                                                                                                |
| Excessive Belt Wear                        | Poor routing of belt                   | Correct route of belt, insure belt is woven through drive and end terminals correctly                                                                                         |
|                                            | Interference within route of belt      | Locate and correct interference issue                                                                                                                                         |
| Belt out of groove<br>Or weakening of belt | High speed                             | Excessive speed in short conveyor units (under 70 linear feet) increases weld fatigue                                                                                         |
|                                            | Maintenance Skew Section               | If 4-foot middle section of intermediate bed is skewed in field, insure belt is properly placed within pressure pan before roller installation (only section skewing allowed) |
|                                            | Lack of power                          | Insure power supply is functioning properly                                                                                                                                   |

| Mechanical Problem     | Possible Cause                             | Remedy                                                                                                                                                                                                                                                 |
|------------------------|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Items not accumulating | Improper wiring of T-cable to power supply | Only the brown and blue wires of the T-cable are used to connect with the Power Supply. If the white and black wires connect in any way... the logic is turn into progressive mode out of singulation, and all function module settings are overridden |
|                        | Broken logic module                        | Located module and replace with new component                                                                                                                                                                                                          |
|                        | Lack of air                                | Insure Filter Regulator is functioning properly, and is set at proper setting. (40psi)                                                                                                                                                                 |
| Zones not releasing    | Cable connector issue                      | Insure proper connection, check for damage.                                                                                                                                                                                                            |

## 18 NBC REPLACEMENT PARTS IDENTIFICATION

---

This section is used to identify parts that may require replacement during the life of the conveyor. Parts, which specifically pertain to MHS Conveyor conveyors, are included with illustrations. A "Recommended Spare Parts List" is published for all conveyor orders of \$20,000. This spare parts list is sent to the purchaser approximately (2) weeks after the order is received. It includes part numbers, description, pricing and recommended quantities to be kept on hand for maintenance. If you are unable to locate this document, another may be obtained by contacting the MHS Conveyor Lifetime Services at 231-798-4547.

### 18.1 SPARE PARTS PRIORITY LEVEL EXPLANATIONS

#### Level #1

**Failure of a priority level #1 spare parts ("A" level part) may cause major disruption of system performance.**

Priority level 1 spare parts must be on-hand, and available to be replaced in the event of a component failure that could shut down a critical function of a conveyor system.

Priority level 1 spare parts include motors, gear reducers, gearmotor, motorized rollers, air solenoid valves, and related components. The majorities of these parts are purchased from MHS Conveyor vendors and carry their own warranties through these vendors. For more warranty information, see MHS Conveyor Equipment Warranty.

#### Level #2

**Failure of a priority level #2 spare parts ("B" level part) usually is gradual and should not cause a major system disruption.**

Priority level 2 spare parts are parts required for smooth system operation and preventative or regular mechanical maintenance.

Priority level 2 spare parts include roller chain, sprockets, belt pulleys, rollers, air cylinders, and other related parts whose failure should not stop a conveyor system suddenly. These parts tend to wear out gradually and are not known to fail suddenly.


#### Level #3

**Priority level #3 parts ("C" level part) rarely fails and are easily obtainable.**

Priority level 3 spare parts are parts that rarely fail or maybe optionally used by the customer.

## 18.2 NBC DRIVE ASSEMBLY

### 18.2.1 NBC 500-AT Drive Assembly




### 18.2.2 Replacement Parts - NBC 500-AT Drive Assembly

| REPLACEMENT PARTS - NBC 500 LB AT DRIVE |                                        |                |           |           |           |
|-----------------------------------------|----------------------------------------|----------------|-----------|-----------|-----------|
| DR-ASY,NBC-28BF-500AT-LH                |                                        | Width & Item # |           |           |           |
| Balloon                                 | Description                            | 16 BF          | 22 BF     | 28 BF     | 34 BF     |
| --                                      | GEARMOTOR                              | SEE CHART      | SEE CHART | SEE CHART | SEE CHART |
| --                                      | DRIVE PULLEY                           | SEE CHART      | SEE CHART | SEE CHART | SEE CHART |
| 06                                      | PULLEY,CABLE 1/4" WIDE X 5" OD         | 1121143        | 1121143   | 1121143   | 1121143   |
| 02                                      | BEARING, R6ZZ C3                       | 90050111       | 90050111  | 90050111  | 90050111  |
| 05                                      | CYLINDER, 2.5" BORE X 28" STK W/ CABLE | 1103837        | 1103837   | 1103837   | 1103837   |
| 13                                      | PULLEY, ASY 6" W/FLANGE                | E0002214       | E0002214  | E0002214  | E0002214  |
| 17                                      | ASY,AIR VALVE NBC 3/8" IN - 1/4" OUT   | 1117620        | 1117620   | 1117620   | 1117620   |
| 40                                      | TOOL,NBC BELT THREADING & INSTRUCTIONS | 1119143        | 1119143   | 1119143   | 1119143   |

REF DWG# 165A001H

### 18.2.3 NBC 250-AT30 Drive Assembly




### 18.2.4 Replacement Parts - NBC 250-AT30 Drive Assembly

| REPLACEMENT PARTS - NBC 250-AT30 |                                        |                |          |          |          |
|----------------------------------|----------------------------------------|----------------|----------|----------|----------|
| DR-ASY,NBC-_BF-250AT30-LH or RH  |                                        | Width & Item # |          |          |          |
| Balloon                          | Description                            | 16 BF          | 22 BF    | 28 BF    | 34 BF    |
| 5                                | PULLEY,ASY 6"DIA W/FLANGE              | E0002214       | E0002214 | E0002214 | E0002214 |
|                                  | CYL,AIR CLIPPARD 2-1/2"BX16"S          | 1166665        | 1166665  | 1166665  | 1166665  |
| 6                                | ROD,END SPHERICAL 1/2" ID,             | 1137475        | 1137475  | 1137475  | 1137475  |
| 2                                | BRG, R6 ZZ C3                          | 90050111       | 90050111 | 90050111 | 90050111 |
| 43                               | ASY,AIR VALVE NBC 250AT DRIVE          | 1185955        | 1185955  | 1185955  | 1185955  |
| 44                               | TUBING,1/4"POLYU-95DURO.160ID          | E0005539       | E0005539 | E0005539 | E0005539 |
| 40                               | TOOL,NBC BELT THREADING & INSTRUCTIONS | 1119143        | 1119143  | 1119143  | 1119143  |
| DWG 165A284                      |                                        |                |          |          |          |





### 18.3.3 NBC 250-AT30 Air Take-Up




### 18.3.4 Replacement Parts - NBC 250-AT30 Air Take-Up

| REPLACEMENT PARTS - NBC 250-AT30 |                                                         |                |          |          |          |
|----------------------------------|---------------------------------------------------------|----------------|----------|----------|----------|
| DR,FRAME ASY NBC-150-AT RH/LH    |                                                         | Width & Item # |          |          |          |
| Balloon                          | Description                                             | 16 BF          | 22 BF    | 28 BF    | 34 BF    |
| 10                               | CARRIAGE, TAKE-UP DR250-AT30 NBC                        | 1167395        | 1167395  | 1167395  | 1167395  |
| 12                               | CYL, ASY NBC DR250-AT30                                 | 1167396        | 1167396  | 1167396  | 1167396  |
| 14                               | GUIDE, BELT DR250 NBC                                   | 1117950        | 1117950  | 1117950  | 1117950  |
| 20                               | LABEL, NBC DRIVE 250 BELT PATH LH                       | 1118030        | 1118030  | 1118030  | 1118030  |
| 21                               | LABEL, NBC DRIVE 250 BELT PATH RH                       | 1118031        | 1118031  | 1118031  | 1118031  |
| 43                               | ASY, SLEEVE VALVE NBC 3/8" IN - 1/4" OUT W/90 ELBOW     | 1168369        | 1168369  | 1168369  | 1168369  |
| 44                               | TUBING, 1/4" POLYU-95DURO.160ID FREELIN WADE #1B-151-10 | E0005539       | E0005539 | E0005539 | E0005539 |

DWG 165S259 A

## 18.4 NBC DRIVE TRAIN


### 18.4.1 NBC 500-AT Drive Trains



## 18.5 REPLACEMENT PARTS - NBC 500 DRIVE TRAINS

| NBC 500# DRIVE TRAINS |                 |               |       |               |         |                |
|-----------------------|-----------------|---------------|-------|---------------|---------|----------------|
| NOMINAL               | DRIVE TRAIN P/N | GEARMOTOR P/N | MOTOR | REDUCER SIZE  | PULLEY  | BORE IN INCHES |
| FPM                   | ITEM 01         | ITEM 01       | HP    | ITEM 01       | ITEM 02 | ITEM 02        |
| 105                   | 1117672         | 1117638       | 1     | SK572.1/80LP  | 1191846 | 1-1/4"         |
| 125                   | 1117674         | 1117640       | 1     | SK372.1/80LP  | 1120871 | 1"             |
| 130                   | 1117676         | 1117642       | 2     | SK572.1/90LP  | 1191846 | 1-1/4"         |
| 165                   | 1117681         | 1117647       | 2     | SK572.1/90LP  | 1191846 | 1-1/4"         |
| 250                   | 1214999         | 1214992       | 3     | SK572.1/100LP | 1191846 | 1-1/4"         |
| Ref DWG# 165S007      |                 |               |       |               |         |                |


### 18.5.1 NBC 250-AT30 Drive Trains



### 18.5.2 Replacement Parts - NBC 250-AT30 Drive Trains

| NBC 250-AT30 DRIVE TRAINS |          |           |         |              |         |           |
|---------------------------|----------|-----------|---------|--------------|---------|-----------|
| NOMINAL<br>FPM            | DR-TRAIN | GEARMOTOR | MOTOR   | REDUCER SIZE | PULLEY  | BORE      |
|                           | P/N      | P/N       | HP      |              |         | IN INCHES |
|                           |          | ITEM 01   | ITEM 01 | ITEM 01      | ITEM 02 | ITEM 02   |
| 125                       | 1117772  | 1117788   | 1       | SK372.1/80LP | 1120871 | 1"        |
| 250                       | 1117783  | 1117799   | 2       | SK372.1/90LP | 1120871 | 1"        |
| Ref DWG # 165S008         |          |           |         |              |         |           |


## 18.6 NBC PRESSURE ASSEMBLY



### 18.6.1 Replacement Parts - NBC Pressure Pans Assembly

| REPLACEMENT PARTS - NBC PRESSURE PAN ASSEMBLY |                               |                |          |          |          |
|-----------------------------------------------|-------------------------------|----------------|----------|----------|----------|
| PAN,PRS ASY 3IN-48Z AC NBC                    |                               | Width & Item # |          |          |          |
| Balloon                                       | Description                   | 16 BF          | 22 BF    | 28 BF    | 34 BF    |
| 2                                             | ROLLER,PRESSURE NBC           | 1109203        | 1109203  | 1109203  | 1109203  |
| 14                                            | CLIP,BELT COVER,MIDDLE NBC    | 1113596        | 1113596  | 1113596  | 1113596  |
| 15                                            | CLIP,BELT COVER,END NBC       | 1113597        | 1113597  | 1113597  | 1113597  |
| 16                                            | DIAPHRAGM,ASY PNEUMATIC 1 AIR | 60710000       | 60710000 | 60710000 | 60710000 |
| 17 & 18                                       | TUBING,1/4" PLYU-90DUR X 13"  | 89000580       | 89000580 | 89000580 | 89000580 |
| REF DWG# 165S004E                             |                               |                |          |          |          |

## 18.7 NBC SKEWED PRESSURE PAN ASSEMBLY




(LH bed, RH skew shown)

### 18.7.1 Replacement Parts - NBC Skewed Pressure Pan Assembly

| REPLACEMENT PARTS - NBC SKEWED PRESSURE PAN ASSEMBLY |                                   |                |          |          |          |
|------------------------------------------------------|-----------------------------------|----------------|----------|----------|----------|
| PAN, PRS ASY 2.25CH-48Z AC NBC LH BED, RH SKEW       |                                   | Width & Item # |          |          |          |
| Balloon                                              | Description                       | 16 BF          | 22 BF    | 28 BF    | 34 BF    |
| 2                                                    | ROLLER, PRS NBC W/ AXLE           | 1118018        | 1118018  | 1118018  | 1118018  |
| 14                                                   | ASY, BELT GUIDE BRKT NBC SKEW PAN | 1132973        | 1132973  | 1132973  | 1132973  |
| 16                                                   | DIAPHRAGM, ASY PNEUMATIC 1 AIR    | 60710000       | 60710000 | 60710000 | 60710000 |
| 17                                                   | TUBING, URETHANE .250OD, .159ID   | 89000580       | 89000580 | 89000580 | 89000580 |
| 18                                                   | TUBING, URETHANE .250OD, .159ID   | 89000580       | 89000580 | 89000580 | 89000580 |
| 21                                                   | BEARING, R6ZZ                     | 90050111       | 90050111 | 90050111 | 90050111 |
| REF DWG# 165S214B                                    |                                   |                |          |          |          |


## 18.8 NBC DISCHARGE BRAKE ASSEMBLY



### 18.8.1 Replacement Parts - NBC Brake Assembly

| REPLACEMENT PARTS - NBC BRAKE ASSEMBLY |                                         |                |          |          |          |
|----------------------------------------|-----------------------------------------|----------------|----------|----------|----------|
| KIT,NBC-__BF-3RC OR 2RC-CTD RLR-BRAKE  |                                         | Width & Item # |          |          |          |
| Balloon                                | Description                             | 16 BF          | 22 BF    | 28 BF    | 34 BF    |
| 01                                     | BRAKE ASSEMBLY                          | 1117955        | 1117955  | 1117955  | 1117955  |
| 02                                     | FITTING, UNION TEE 1/4" T               | 89000530       | 89000530 | 89000530 | 89000530 |
| 03                                     | BUMPER, BRAKE PAD                       | 1113368        | 1113368  | 1113368  | 1113368  |
| 04                                     | DIAPHRAGM, ASY PNEUMATIC SINGLE STEM    | 60710000       | 60710000 | 60710000 | 60710000 |
| 20                                     | ORING, 83A ST TRNS 3/16" X 9-15/16      | 90530005       | 90530005 | 90530005 | 90530005 |
| 22                                     | ROLLER, ITR 1.9 PLTD PRBG               | E0002412       | E0002413 | E0002414 | E0006220 |
| 23                                     | ROLLER, PLASTIC COAT 2D 1.9 CTD - 3" RC | 1119631        | 1119632  | 1119633  | 1119634  |
| ----                                   | ROLLER, PLASTIC COAT 2D 1.9 CTD - 2" RC | 1127420        | 1127421  | 1127422  | 1127423  |
| ----                                   | BRAKE KIT ASY, INCLUDES ROLLERS - 3" RC | 1118098        | 1118099  | 1118100  | 1118101  |
| ----                                   | BRAKE KIT ASY, INCLUDES ROLLERS - 2" RC | 1129547        | 1129548  | 1129549  | 1129550  |
| Dwg# 165S104B                          |                                         |                |          |          |          |

## 18.9 NBC END PULLEY ASSEMBLY



(Charge / Discharge)

### 18.9.1 Replacement Parts- NBC Terminal Pulley


| REPLACEMENT PARTS - NBC TERMINAL PULLEY |                              |                |          |          |          |
|-----------------------------------------|------------------------------|----------------|----------|----------|----------|
| ASY, TERMINAL PULLEY NBC                |                              | Width & Item # |          |          |          |
| Balloon                                 | Description                  | 16 BF          | 22 BF    | 28 BF    | 34 BF    |
| 07                                      | PULLEY, ASY 6" DIA FLAT FACE | E0002215       | E0002215 | E0002215 | E0002215 |
| 08                                      | PULLEY, ASY 6" DIA W/FLANGE  | E0002214       | E0002214 | E0002214 | E0002214 |
| 05                                      | ACTUATOR, SHEAVE ASY         | E0002212       | E0002212 | E0002212 | E0002212 |
| 03                                      | GUIDE, BELT END NBC          | 1117517        | 1117517  | 1117517  | 1117517  |
| 11                                      | SPACER, 11/16 HEX X .281L    | 1114361        | 1114361  | 1114361  | 1114361  |
| Dwg# 165S019                            |                              |                |          |          |          |



### 18.10.1 Replacement Parts - NBC Contact Accumulation


| REPLACEMENT PARTS - NBC CONTACT ACCUMULATION |                                                     |                |          |          |          |  |
|----------------------------------------------|-----------------------------------------------------|----------------|----------|----------|----------|--|
| BED,NBC- BF-C48-IN-CZ-2rc OR 3RC-LH/RH       |                                                     | Width & Item # |          |          |          |  |
| Balloon                                      | Description                                         | 16 BF          | 22 BF    | 28 BF    | 34 BF    |  |
| ----                                         | <b>HARNESS,ASY NBC 48" 3 ZONE LH ATB</b>            | ----           | ----     | ----     | ----     |  |
| 04/01                                        | LM,ASY AIR TO BRAKE W/PE BRKT & HDWE                | 1115898        | 1115898  | 1115898  | 1115898  |  |
| ----                                         | <b>PE,REFLECTOR W/ FOAM TAPE HORIZONTAL MOUNTED</b> | ----           | ----     | ----     | ----     |  |
| 06/10                                        | PE,REFLECTOR 4-3/8" X 1-1/8"                        | 400004         | 400004   | 400004   | 400004   |  |
| ----                                         | <b>ASY,RETURN ROLLER NBC</b>                        | ----           | ----     | ----     | ----     |  |
| 30/02                                        | ACTUATOR,SHEAVE ASY                                 | E0002212       | E0002212 | E0002212 | E0002212 |  |
| ----                                         | STANDOFF,ACTUATOR,SHEAVE ASY                        | E0002213       | E0002213 | E0002213 | E0002213 |  |
| -----                                        | <b>PAN,PRS ASY</b>                                  | ----           | ----     | ----     | ----     |  |
| 09/02                                        | ROLLER,PRESSURE NBC                                 | 1109203        | 1109203  | 1109203  | 1109203  |  |
| 09/16                                        | DIAPHRAGM,ASY PNEUMATIC 1 AIR SINGLE AIR INLET      | 60710000       | 60710000 | 60710000 | 60710000 |  |
| ----                                         | TUBING,URETHANE .250OD,.159ID                       | 89000580       | 89000580 | 89000580 | 89000580 |  |
| 09/21                                        | BRG, R6 ZZ C3                                       | 90050111       | 90050111 | 90050111 | 90050111 |  |
|                                              | <b>BED,NBC- BF</b>                                  | ----           | ----     | ----     | ----     |  |
| 20                                           | ORING,83A ST TRNS 3/16X9-15/16                      | 90530005       | 90530005 | 90530005 | 90530005 |  |
| 21                                           | ROLLER, "GRAV 1.9 PLTD PRBG                         | 60218009       | 60224009 | 60230009 | 60236009 |  |
| 22                                           | ROLLER, ITR 1.9PLTD PRBG                            | E0002412       | E0002413 | E0002414 | E0006220 |  |
| ----                                         | <b>HOSE, CLEAR</b>                                  | ----           | ----     | ----     | ----     |  |
| ----                                         | TUBING,POLYETHYLENE 3/8 OD,CLR                      | 89000585       | 89000585 | 89000585 | 89000585 |  |
| Dwg# 165A000                                 |                                                     |                |          |          |          |  |

## 18.11 NBC Logic Module Component



Air to brake logic module - Straight Beds

## 18.12 NBC 12 FT. CONTACT ACCUMULATION SKEWED ROLLERS




(LH Bed with RH Skew shown)

### 18.12.1 Replacement Parts - NBC 12ft Contact Accumulation Skewed Rollers

| Replacement Part Numbers for NBC Contact Accumulation Skewed Rollers<br>(LH Bed with RH Skew Shown) |          |         |                                |         |         |         |
|-----------------------------------------------------------------------------------------------------|----------|---------|--------------------------------|---------|---------|---------|
| BALLOON                                                                                             | ROLLERS  | QTY     | 16BF                           | 22BF    | 28BF    | 34BF    |
| 21                                                                                                  | NO GRVS  | 53      | 1154835                        | 1154836 | 1154837 | 1154838 |
| 50                                                                                                  | S        | 3,3,4,4 | 1154831                        | 1154832 | 1154833 | 1154834 |
| 52                                                                                                  | B        | 1       | ---                            | 1121728 | ---     | ---     |
| 53                                                                                                  | C        | 4,3,3,3 | 1118554                        | 1121729 | 1118079 | 1119832 |
| 54                                                                                                  | D        | 1       | 1118555                        | 1121730 | 1118080 | 1119833 |
| 55                                                                                                  | E        | 2       | 1118557                        | 1121731 | 1118086 | 1119834 |
|                                                                                                     |          |         |                                |         |         |         |
| BALLOON                                                                                             | ITEM #   | QTY     | DESCRIPTION                    |         |         |         |
| 20                                                                                                  | 90530003 | 8       | ORING,83A CURVE TRNS. 3/16"X9" |         |         |         |
| Dwg# 165A162H                                                                                       |          |         |                                |         |         |         |

### 18.13 NBC 12 FT. CONTACT ACCUMULATION SKEWED ROLLERS



(RH Bed with RH Skew shown)

#### 18.13.1 Replacement Parts - NBC 12ft Contact Accumulation Skewed Rollers

| Replacement Part Numbers for NBC Contact Accumulation Skewed Rollers<br>(RH Bed with RH Skew Shown) |          |         |                                |         |         |         |
|-----------------------------------------------------------------------------------------------------|----------|---------|--------------------------------|---------|---------|---------|
| BALLOON                                                                                             | ROLLERS  | QTY     | 16BF                           | 22BF    | 28BF    | 34BF    |
| 21                                                                                                  | NO GRVS  | 52      | 1154835                        | 1154836 | 1154837 | 1154838 |
| 50                                                                                                  | S        | 3,4,5,5 | 1154831                        | 1154832 | 1154833 | 1154834 |
| 52                                                                                                  | B        | 1       | ---                            | ---     | 1118078 | 1119831 |
| 53                                                                                                  | C        | 4,3,2,2 | 1118554                        | 1121729 | 1118079 | 1119832 |
| 54                                                                                                  | D        | 1       | 1118555                        | 1121730 | 1118080 | 1119833 |
| 55                                                                                                  | E        | 3,3,2,2 | 1118557                        | 1121731 | 1118086 | 1119834 |
| BALLOON                                                                                             | ITEM #   | QTY     | DESCRIPTION                    |         |         |         |
| 20                                                                                                  | 90530003 | 9       | ORING,83A CURVE TRNS. 3/16"X9" |         |         |         |

Dwg# 165A017G

## NBC REVISION HISTORY

---

| Revision Date | Chapter and Description                                                                   | Initials |
|---------------|-------------------------------------------------------------------------------------------|----------|
| 06/18/2021    | New Spanish IOM available                                                                 | AB / MD  |
| 06/18/2021    | Added new packaging & part location for skew section                                      | MM       |
| 09/28/2021    | Add MHS Conveyor name, logo, and format                                                   | MD AB    |
| 12/2/2021     | Updated Drive train spare parts list & add belt tracking to weekly maintenance inspection | AB / MW  |
| 02/28/2022    | Updated part list to DWG 165S007                                                          | DG / MD  |
| 08/01/2022    | Removed skew packaging location for skew beds.                                            | DG       |
|               |                                                                                           |          |

## WORKS CITED

---

CEMA. (2014). *Conveyor Equipment Manufacturers Association*. Retrieved 2014, from Conveyor Equipment Manufacturers Association: <http://www.cemanet.org/>

Nord. (2015). *Nord Drivesystems*. Retrieved from Nord Drivesystems: <https://www.nord.com/cms/us/home-us.jsp>

OSHA. (2014). *Occupational Safety & Health Administration*. Retrieved 2014, from OSHA QuickTakes: <https://www.osha.gov/>

## GENERAL MHS CONVEYOR

---

Para obtener manuales, videos y otros recursos adicionales, visite nuestro sitio web en:

[www.mhs-conveyor.com](http://www.mhs-conveyor.com)

## ABOUT MHS CONVEYOR

---

### About MHS Conveyor

MHS Conveyor, located in Norton Shores, Michigan, is a leading deliverer of “smart” material handling systems, technologies, products, and services, creating solutions for material flow applications. As a global supplier of conveyor systems and equipment since 1964, MHS Conveyor provides sorters, conveyors, and accessories to satisfy a broad spectrum of accumulation, transportation, and sortation applications.



**MHS Conveyor Corp.**  
**1300 E. Mount Garfield Road**  
**Norton Shores MI 49441-6097 USA**  
**231.798.4547**  
Email : [usinfo@mhs-conveyor.com](mailto:usinfo@mhs-conveyor.com)  
Web Site : [mhs-conveyor.com](http://mhs-conveyor.com)



Regional sales offices and authorized Business Partners located throughout the United States and Canada. Licensees and Business Partners in Europe, South America, and Southeast Asia.